

ULTRASONIC FLOWMETER FUM-1000

Instruction Manual

FUM-1000, Rev. 1, JUN 2016



Flow & Level Instruments

FLOVEL CO., LTD.

70-6, Bamdwi-gil 42 beon-gil, Paltan-myeon, Hwaseong-si,
Gyeonggi-do, KOREA, ZIP 18524

TEL. +82-31-415-9992~4 FAX. +82-31-357-5984

www.flovel.co.kr

e-mail : flovel9992@hanmail.net

Important Customer Notice

Thank you for choosing the FUM-1000 Transit-Time Ultrasonic Flow Meter with SLSI CMOS and low-voltage wide-pulse sending technology. This manual contains important information about your meter. Before installing and operating this flow meter, please read this manual carefully and follow its instructions.

- FLOVEL has verified the conformity between the contents in this manual and the hardware and software described. However, errors may still exist. We regularly review the materials covered in this manual and correct errors with revisions. Any suggestions for improvement will be appreciated.
- Go to <http://www.flovel.co.kr/> for a most current electronic version of this manual.
- We reserve the right to change the content of this manual without prior notification.
- If you have any questions or problems regarding this manual, please contact FLOVEL Service




FLOVEL Service

TEL. +82-31-415-9994 FAX. +82-31-357-5984

e-mail : flovel9992@hanmail.net


WARNINGS IN THIS MANUAL

Warning, attention, and note statements are used throughout this book to draw your attention to important information.

	<p>WARNING</p> <p>“Warning” statement appears with information that is important to protect people and equipment from damage. Pay very close attention to all warnings that apply to your application. Failure to comply with these instructions may damage the meter and personal injury.</p>
	<p>ATTENTION</p> <p>“Attention” statements in this manual indicate that failure to comply with stated instructions may result in damage to the meter or faulty operation of the flow meter.</p>
	<p>NOTE</p> <p>“Note” indicates that ignoring the relevant requirements or precautions may result in flowmeter damage or malfunction.</p>

Product Components

An inspection should be made before installing the flow meter. Check to see if the spare parts are in accordance with the packing list. Make sure that there is no damage to the enclosure due to a loose screw or loose wire, or other damage that may have occurred during transportation. Any questions, please contact your representative as soon as possible.

	
<p style="text-align: center;">Transmitter</p>	<p style="text-align: center;">Sensor</p>
 <ol style="list-style-type: none"> 1. Special Cable (1 set) 2. Sensor Mounting Bracket (1 set) 3. Sensor Mounting Wire (1 set) 4. Adjusting Bolts (1 set) 5. Wire Clamp (1 set) 6. Grease (1 ea) 	<ol style="list-style-type: none"> 1. Instruction Manual 2. Packing List 3. Report for 4-point factory Calibration
<p style="text-align: center;">Accessory</p>	<p style="text-align: center;">Document</p>


CONTENT

1. Transmitter Installation and Connect -----	5
1.1. Inspection Prior to Transmitter Installation-----	5
1.2 Power Supply Connecting-----	6
1.3. Powering on-----	6
1.4. Keypad Functions-----	7
1.5. Keypad Operation-----	7
1.6. Flowmeter Window Descriptions-----	9
2. Pipe Parameter Entry Shortcuts -----	10
3. Measurement Site Selection -----	12
3.1 Selection of Measurement point-----	12
3.2 Installation of Ultrasonic Flowmeter-----	13
4. Transducer Installation -----	14
4.1. Installing the Transducers-----	14
4.2. Transducer Mounting Inspection-----	16
5. Operating Instructions -----	19
5.1. System Normal Identification format change of entire section-----	19
5.2. Zero Set Calibration-----	19
5.3. Scale Factor-----	20
5.4. System Lock (Unlock)-----	20
5.5. Keypad Lock-----	21
5.6. 4~20mA Current Loop Verification-----	21
5.7. Frequency Output-----	21
5.8. Totalizer Pulse Output-----	22
5.9. Alarm Programming-----	22
5.10. Batch Controller Paragraph format change-----	23
5.11. Analog Output Calibration-----	24
6. Windows Display Explanations -----	25
6.1. Windows Display Codes-----	25
6.2. Display Explanation-----	27
7. Error Diagnoses -----	44
8. Product Overview -----	47
9. Appendix -----	50

1. Transmitter Installation and Connect


1.1. Inspection Prior to Transmitter Installation

You will find a "Position Drawing" in the packing. Please use it as a template in the place that you are going to install the flow meter. Then drill 3 installation holes at the screw position shown on the drawing with the M5 mm aiguilles. (picture)



Instructions:

1. Screw M5X10mm 1 ea, M5X20mm 2ea tapping screws through the transmitter enclosure base and attach it to the wall.
2. Tighten the screws to secure to the enclosure on the wall.

	<p>ATTENTION</p> <p>When installing please make sure that the installing face can afford the flow meter to avoid falling off. And make sure the installing face is dry.</p>
---	--

1.2 Power Supply Connecting

1.2.1. Direct Mount Method

Please double check that power supply you ordered meets your equipment requirements. Factory standard power supply is 90~245 VAC.


Observe the following precautions for installation procedures outlined in this chapter:


- Ensure that power connections are made in accordance with the indications shown on the connection terminals.
- Transmitters can be powered by two different power supplies: 90~245VAC or 10-36VDC

1.2.2. Connecting the Wiring

Once the electronics enclosure has been installed, the flow meter wiring can be connected. Open the case, terminals 11, 12, and 13 can be found at the left lower side. Connect to AC power. Terminal 13 is grounded (earth) while connecting. As per wiring diagram to connect 4-20mA Output (terminals 23, 24), Downstream transducer (terminals 44, 45, 46), Upstream transducer (terminals 41, 42, 43), OCT Output (terminals 28, 29) and Relay Output(terminals 30, 31).

For double-shielded transducer cable: "-" on the black wire, "+" on the red wire and "shield" on the shield.



	<p>WARNING</p> <p>Wire with power off.</p> <p>Use either AC or DC power supply. Do not connect them both at the same time.</p>
---	---

1.3. Powering on

As soon as the flow meter is switched on, the self-diagnosis program will start to run. If any error is detected, an error code will display on the screen (Refer - Error Diagnoses). After that, the system will run automatically according to the last input parameters.

If the installation is accomplished when system is switched on, gain adjustment can be monitored in Window M01. After S1, S2, S3, and S4 are displayed on the upper left corner of the screen, the system will activate the normal measurement condition automatically. It is indicated by code “*R” on



the upper left corner of the screen. The system will default to the last window settings and automatically display them at next power on.


1.4. Keypad Functions




Follow these guidelines when using the flow meter keypad (Refer to Keypad Figure):

0 ~ 9 And  input numbers.

Backspace or delete characters to the left.

 And  Return to the last menu or to open the next menu. These buttons act as “UP” and “DN” functions when entering numbers.

 Select a menu. Press this key first, input two menu numbers and then enter the selected menu.





For example, To Input a pipe outside diameter, press    keys where “11” is the window ID to display the parameter for pipe outside diameter.












1.5. Keypad Operation


With all of the parameters entered, the instrument setup and measurement displays are subdivided or consolidated into more than 100 independent windows. The operator can input parameters, modify settings or display measurement results by “visiting” a specific window. These window are arranged by 2-digit serial numbers (including “UP” sign) from 00~99, then to +0, +1, etc. Each window serial number, or so-called window ID code, has a defined meaning.

For example, Window M11 indicates the parameter input for pipe outside diameter, while Window M25 indicates the mounting spacing between the transducers, etc. (Refer DN Windows Display Explanations).

The keypad shortcut to visit a specific window is to press the  key at any time, then input the 2-digit window ID code. For example, to input or check the pipe outside diameter, just press the    keys for window ID code 11.

Another method to visit a particular window is to press   and  keys to scroll the screen. For example, if the current window ID code is 66, press  key to enter Window M65, press the  button again to enter Window M64; then, press the  key to back Window M65, and press the  key again to enter Window M66.

<p>Example 1: To enter a pipe outside diameter of 219.234, the procedure is as follows: Press Menu 1 1 keys to enter Window M11 (the numerical value displayed currently is a previous value). Now press ENT key. The symbol ">" and the flashing cursor are displayed at the left end of the second line on the Screen. The new value can be entered then...2 1 9</p>	
<p>Example 2: If the pipe material is "Stainless Steel", press keys Menu 1 4 to enter Window M 14 first. Then press ENT key to modify the options. Now, select the "1. Stainless Steel " option by pressing UP and DN keys, and then press ENT key to confirm the selection. It is possible to press the 5 key to change the election and wait until "5. PVC" is displayed on the second line of the screen. Then press the ENT key to confirm.</p>	


	<p>ATTENTION</p> <p>Generally, press ENT key first if operator wants to enter "modify" condition. If the "modify" is still not possible even after pressing the ENT key, it means that system is locked by a password. To "Unlock" it, select "Unlock" in Window M47 and enter the original password. The keypad will not respond if the keypad is locked. It only can be unlocked by the entering original password. Select keypad lock functions in Window M48.</p>
---	--

1.6. Flowmeter Window Descriptions

The Flowmeter has the unique feature of windows processing for all operations.

These windows are assigned as follows:

00~09	Flow Totalizer Display: to display flow rate, positive total, negative total, net total, velocity, date & time, analog inputs for present flow, present operation and flow results today, etc.
10~29	Initial Parameter Setup: to enter pipe outside diameter, pipe wall thickness, fluid type, transducer type, transducer mounting and spacing, etc.
30~38	Flow Units Options: to select the flow unit, totalizer unit, measurement unit, turn totalizers on/off and reset totalizes, etc.
40~49	Setup options: Scaling factor, network IDN (Window M46), system lock (Window M47) and keypad lock code (Window M48), etc.
50~89	Input and output setup: relay output setup, 4-20mA outputs, flow batch controller, LCD backlit option, date and time, low/high output frequency, alarm output, date totalizer, etc.
90~95	Diagnoses: Signal strength and signal quality (Window M90), TOM/TOS*100 (Window M91), flow sound velocity (Window M92), total time and delta time (Window M93), Reynolds number and factor (Window M94), Data Interval (Window M95) etc.
+0~+5	Appendix: power on/off time, total working hours, on/off times and a single-accuracy function calculator.

	<p>ATTENTION</p> <p>The other windows are for hardware adjustment by the manufacturer.</p>
---	---

2. Pipe Parameter Entry Shortcuts

Below is an example of a typical shortcut keypad entry for pipe parameters. For example the parameters in this example are: measuring the diameter of DN125, measuring medium is water, pipe material is PVC, no liner material. This example can be operated as follows:


<p>Step1. Pipe outside diameter:</p> <p>Press Menu 1 1 keys to enter Window M11, and enter the pipe outside diameter, and then press the ENT key.</p>	<p>Pipe Outer Diameter >140</p>
<p>Step2. Pipe wall thickness</p> <p>Press the DN key to enter Window M12, pipe wall thickness, and press the ENT key.</p>	<p>Pipe Wall Thickness >7.5</p>
<p>Step3. Pipe material</p> <p>Press the DN key to enter Window M14, press the ENT key, move the UP or DN key to select pipe material, and press the ENT key.</p>	<p>Pipe Material [14 >5. PVC</p>
<p>Step4. Liner material parameters (including thickness and sound velocity, if needed)</p> <p>Press the DN key to enter Window M16, press the ENT key, move the UP or DN key to select liner material, and press the ENT key.</p>	<p>Linner Material [16 >0. None, No Liner</p>
<p>Step5. Fluid type</p> <p>Press the DN key to enter Window M20, press the ENT key, move the UP or DN key to select fluid type, press the ENT key.</p>	<p>Fluid Type [20 >0. Water</p>
<p>Step6. Transducer type (The transmitter is available for various transducer types.)</p> <p>Press the DN key to enter Window M23, press the ENT key, move the UP or DN key to select transducer type, and press the ENT key.</p>	<p>Transducer Type [23 >23. Standard L2</p>
<p>Step7. Transducer mounting methods</p> <p>Press the DN key to enter Window M24, press the ENT key, move the UP or DN key to select transducer-mounting method, and press the ENT key.</p>	<p>Transducer Mounting >0. V</p>

<p>Step8. Adjust Transducer spacing</p> <p>Press the DN key to enter Window M25, accurately install the transducer according to the displayed transducer mounting spacing and the selected mounting method (Refer to Installing the Transducers in this chapter).</p>	<div style="border: 2px solid yellow; padding: 5px; text-align: center;"> <p>Transducer Spacing 73.413 mm</p> </div>
<p>Step9. Initial Parameter Setups and Save</p> <p>Press the Manu 26 keys to ENT key.</p>	<div style="border: 2px solid yellow; padding: 5px; text-align: center;"> <p>Parameter Setups Entry to SAVE</p> </div>
<p>Step10. Display measurement result</p> <p>Press the Menu 0 1 keys to enter Window M01 to display measurement result.</p>	<div style="border: 2px solid yellow; padding: 5px; text-align: center;"> <p>Flow 123.456 m3/h *R Vel 3.8764 m/s</p> </div>

3. Measurement Site Selection

When selecting a measurement site, it is important to select an area where the fluid flow profile is fully developed to guarantee a highly accurate measurement. Use the following guidelines to select a proper measurement installation site:

Choose a section of pipe, which is always full of liquid, such as a vertical pipe with flow in the upward direction or a full horizontal pipe.



3.1 Selection of Measurement point

To selecting the correct measuring point is the most important, precise measurements should be as follows in order.

- 1) Select the kinds of liquid and fill up liquid at inside of the pipes.
- 2) Choose measurement point at 10D from the upstream and at 5D from downstream. Any valves among the measurement points should not be installed.
- 3) Check the operating temperature of measurement points. (Check the fluid emperature)
- 4) A pump or curve pipe is installed straight pipe on point 30D.
- 5) Considering the state of the pipe wall, install a pipe on point of the clear condition.
- 6) For make it easier to launch ultrasonic, find average point and make contact with the surface of the pipe closely.

3.2 Installation of Ultrasonic Flowmeter (Upstream & Downstream Requirements)













Name	Straight length of upstream piping	Straight length of downstream piping
90° bend		
Tee		
Diffuser		
Reducer		
Valve	 <p data-bbox="598 1355 837 1388">Flow controlled upstream</p>	 <p data-bbox="1085 1355 1348 1388">Flow controlled downstream</p>
Pump		

Fig 3. Installation Conditions

4. Transducer Installation

4.1. Installing the Transducers

Before installing the transducers, clean the pipe surface where the transducers are to be mounted. Remove any rust, scale or loose paint and make a smooth surface. Choose a section of sound conducting pipe for installing the transducers. Apply a wide band of sonic coupling compound down the center of the face of each transducer as well as on the pipe surface, and then attach the transducers to the pipe with the straps provided and tighten them securely.

	<p>NOTE</p> <p>The two transducers should be mounted at the pipe's centerline on horizontal pipes.</p> <p>Make sure that the transducer mounting direction is parallel with the flow.</p> <p>During the installation, there should be no air bubbles or particles between the transducer and the pipe wall. On horizontal pipes, the transducers should be mounted in the 3 o'clock and 9 o'clock positions of the pipe section in order to avoid any air bubbles inside the top portion of the pipe. (Refer to Transducer Mounting). If the transducers cannot be mounted horizontally symmetrically due to limitation of the local installation conditions, it may be necessary to mount the transducers at a location where there is a guarantee full pipe condition (the pipe is always full of liquid).</p>
---	---

4.1.1. Transducer spacing

After entering the required parameters, the spacing between the ENDS of the two transducers is considered as the standard transducer spacing (Refer to Top View on transducer mounting methods in diagram below). Check the data displayed in Window M25 and space the transducers accordingly.

4.1.2. Transducer Mounting Methods

Four transducer mounting methods are available. They are respectively: V method, Z method, N method, and W method. The V method is primarily used on small diameter pipes (DN100~400mm, 4"~16"). The Z method is used in applications where the V method cannot work due to poor signal or no signal detected. In addition, the Z method generally works better on larger diameter pipes (over DN300mm, 12") or cast iron pipes. The N method is an uncommonly used method as well as

is the W method. They are used on smaller diameter pipes (below DN50mm, 2”).

4.1.3. V Method

The V method is considered as the standard method. The V method usually gives a more accurate reading and is used on pipe diameters ranging from 25mm to 400mm (1~16”) approximately. Also, it is convenient to use, but still requires proper installation of the transducer, contact on the pipe at the pipe’s centerline, and equal spacing on either side of the centerline.




Fig 3. Sensor Installation (“V” Method)

4.1.4. Z Method

The signal transmitted in a Z method installation has less attenuation than a signal transmitted with the V method. This is because the Z method utilizes a directly transmitted (rather than reflected) signal which transverses the liquid only once. The Z method is able to measure on pipe diameters ranging from 100mm to 3000mm (4”~120”) approximately. Therefore, we recommend the Z method for pipe diameters over 300mm (12”).




Fig 4. Sensor Installation (“Z” Method)

4.1.5. N Method (not commonly used)

With the N method, the sound waves traverse the fluid twice and bounce three times off the pipe walls. It is suitable for small pipe diameter measurement. The measurement accuracy can be improved by extending the transit distance with the N method (uncommonly used).

4.1.6. W Method (very rarely used)

As with the N method, the measurement accuracy can also be improved by extending the transit distance with the W method. The sound wave traverses the fluid four times and bounces four times off the pipe walls. It is suitable for very small pipe (diameters less than 50mm, 2”).

4.2. Transducer Mounting Inspection

Check to see if the transducer is installed properly and if there is an accurate and strong enough ultrasonic signal to ensure proper operation and high reliability of the transducer. You can confirm that the transducer is installed correctly by checking the detected signal strength, total transit time, and delta time as well as transit time ratio.

The “mounting” condition directly influences the flow value accuracy and system long-time running reliability. In most instances, only apply a wide bead of sonic coupling compound lengthwise on the face of the transducer and stick it to the outside pipe wall to get good measurement results. However, the following inspections still need to be carried out in order to ensure the high reliability of the measurement and long-term operation of the instrument.

4.2.1. Signal Strength Inspection

Signal strength (displayed in Window M90) indicates a detected strength of the signal both from upstream and downstream directions. The relevant signal strength is indicated by numbers from 00.0~99.9. 00.0 represents no signal detected while 99.9 represent maximum signal strength. Normally, the stronger the signal strength detected, the longer the operation of the instrument reliably, as well as the more stable the measurement value obtained.

Adjust the transducer to the best position and check to ensure that enough sonic coupling compound is applied adequately during installation in order to obtain the maximum signal strength. The FUM-1000 system normally requires signal strength over 60.0, which is detected from both upstream and downstream directions. If the signal strength detected is too low, the transducer installation position and the transducer mounting spacing should be re-adjusted and the pipe should be re-inspected. If necessary, change the mounting to the Z method.

4.2.2. Signal Quality (Q value) Inspection


Q value is short for Signal Quality (displayed in Window M90). It indicates the level of the signal detected. Q value is indicated by numbers from 00~99. 00 represents the minimum signal detected while 99 represent the maximum. Normally, the transducer position should be adjusted repeatedly and coupling compound application should be checked frequently until the signal quality detected is as strong as possible.


4.2.3. Total Time and Delta Time Inspection

“Total Time and Delta Time”, which displays in Window M93, indicates the condition of the installation. The measurement calculations in the flow meter are based upon these two parameters. Therefore, when “Delta Time” fluctuates widely, the flow and velocities fluctuate accordingly. This means that the signal quality detected is too poor. It may be the results of poor pipe-installation conditions, inadequate transducer installation, or incorrect parameter input. Generally, “Delta Time” fluctuation should be less than $\pm 20\%$. Only when the pipe diameter is too small or velocity is too low can the fluctuation be wider.

4.2.4. Transit Time Ratio

Transit Time Ratio indicates if the transducer mounting spacing is accurate. The normal transit time ratio should be 100 ± 3 if the installation is proper. Check it in Window M91.

	<p>ATTENTION</p> <p>If the transit time ratio is over 100 ± 3, it is necessary to check:</p> <ul style="list-style-type: none"> A. If the parameters (pipe outside diameter, wall thickness, pipe material, liner, etc.) have been entered correctly, B. If the transducer mounting spacing is accordance with the display in Window M25, C. If the transducer is mounted at the pipe's centerline on the same diameter, D. If the scale is too thick or the pipe mounting is distorted in shape, etc.
---	--

	<p>Warnings</p> <ul style="list-style-type: none"> A. Pipe parameters entered must be accurate; otherwise the flow meter will not work properly. B. During the installation, apply enough coupling compounds in order to stick the transducer onto pipe wall. While checking the signal strength and Q value, move the transducer slowly around mounting site until the strongest signal and maximum Q value can be obtained. Make sure that larger the pipe diameter, the more the transducer should be moved.
---	--

	<ul style="list-style-type: none">C. Check to be sure the mounting spacing is accordance with the display in Window M25 and transducer is mounted at the pipe's centerline on the same diameter.D. Pay special attention to those pipes that formed by steel rolls (pipe with seams), since such always irregular. If the signal strength is always displayed as 0.00, that means there is no detected. Thus, it is necessary to check that the parameters (including all the pipe parameters) been entered accurately. Check to be sure the transducer mounting method has been selected properly, the pipe is not worn-out, and the liner is not too thick. Make sure there is there is indeed fluid pipe or the transducer is not very close to a valve or elbow, and there are not too many air bubbles the fluid, etc. With the exception of these reasons, if there is still no signal detected, the measurement site has to be changed.E. Make sure that the flowmeter is able to run properly with high reliability. The stronger the strength displayed, the higher the Q value reached. The longer the flowmeter runs accurately, higher the reliability of the flow rates displayed. If there is interference from ambient electromagnetic waves or the signal detected is too poor, the flow value displayed is not reliable; consequently, capability for reliable operation is reduced.F. After the installation is complete, power on the instrument and check the result accordingly.
--	--

5. Operating Instructions

5.1. System Normal Identification format change of entire section

Press the Menu 0 8 keys. If the letter “*R” displays on the screen, it indicates system normal.

If the letter “E” is displayed, it indicates that the current loop output is over ranged by 120%. This refers to the settings in Window M57. Enter a larger value in Window M57, and the letter “E” will disappear. It can be ignored if no current loop output is used.

If the letter “Q” is displayed, it indicates that the frequency output is over ranged by 120%, and this refers to the settings in Window M69. Increase the input value in Window M69, and the letter “Q” will disappear. It can be ignored if no frequency output is used.

If the letter “H” is displayed, it indicates that the ultrasonic signal detected is poor. For more information, please refer to “Error Diagnoses”.

If the letter “G” is displayed, it indicates that system is adjusting the signal gain prior to the measurement. Also, it means system normal. Only when the adjustment takes too long without stopping, can system be identified as abnormal.


Letter “I” indicates no signal is being detected. Check the transducer wiring connections are correct, the transducers are installed firmly, etc.

Letter “J” indicates a hardware defect exists. Normally, such defect is temporary; it could be eliminated by system reboot (power off and restart). For further information, please refer to “Error Diagnoses”.

5.2. Zero Set Calibration

Once zero flow occurs, a zero point may indicate on each measuring instrument, i.e. as the measurement value reaches zero flow, it is indicated as zero. It is necessary to establish the true zero flow condition and program that set point into the instrument.

If the zero set point is not at true zero flow, a measurement difference may occur. The smaller the physical measurement capacity is, the larger the measurement difference from the zero point will exist. Only when zero point is reduced to a definite degree, as compared with the physical measurement capacity, can the measuring difference from zero point be ignored.

	<p>NOTE</p> <p>For an ultrasonic flow meter, the measurement difference from zero point cannot be ignored at low flow. It is necessary to perform a zero set calibration to improve low flow measurement accuracy.</p>
---	---

5.3. Scale Factor

Scale factor refers to the ratio between “actual value” and “reading value”. For example, when the measurement is 2.00, and it is indicated as 1.98 on the instrument, the scale factor reading is 2/1.98. This means that the best scale factor constant is 1. However, it is difficult to keep the scale factor as “1” on the instrument especially in batch control operations. The difference is called “consistency”. High quality products always require high consistency. The scale factor default is “1” for each instrument prior to shipment from the factory. The reason setting the scale factor default is that the scale factors in the flow meter are only limited by two parameters: the crystal oscillation frequency and the transducer. It has no relation to any circuit parameters.


During operation, there still exists possible difference in pipe parameters, etc. The “scale factor” may be necessary when used on different pipes. Thus, scale factor calibration is specially designed for calibrating the differences that result from application on different pipes. The scale factor entered must be one that results from actual calibration.

5.4. System Lock (Unlock)

System lock is readable but unable to prevent operation error due to unauthorized tampering by unauthorized personnel.

Press the Menu 4 7 ENT keys, move / + or / - key to select “Lock”, press the ENT key, enter a 1~4 numerically long password, and then press the ENT key to confirm.

Unlock using the selected password only. Press Menu 4 7 ENT , move / + or / - to select “Unlock”, press ENT , enter the correct password, then press ENT to confirm.

	<p>ATTENTION</p> <p>Keep the password in mind or recorded in a safe place or the instrument cannot be used.</p>
---	--

5.5. Keypad Lock

The keypad can be locked to prevent unauthorized use of your flow meter. Unlock it using the correct password only.

To lock it, first enter desired window, then press Menu 4 8 press ENT to enter a 1~8 numerically long password, and then it will return to the locked window automatically. For example, if Window M01 is required to display in the locked condition, enter Window M01 first (if already in this window, skip this step), press Menu 4 8 , press ENT to enter a password such as “1111”, press ENT again to return to the locked Window M01 automatically. The keypad is “invalidated” now. Unlock it by entering the password “1111” again.

5.6. 4~20mA Current Loop Verification

Possessing a current loop output exceeding an accuracy of 0.1%, the flow meter is programmable and configurable with multiple output modules such as 4 ~20mA or 0~20mA. Select in Window M55. For details, please refer to “Windows Display Explanations”.

In Window M56, enter a 4mA flow value. Enter the 20mA flow value in Window M57. For example, if the flow range in a specific pipe is 0~1000m³/h, enter 0 in Window M56 and 1000 in Window M57. If the flow ranges from -1000~0~2000m³/h, configure the 20~4~20mA module by selecting Window M55 when flow direction is not an issue. Enter 1000 in Window M56 and 2000 in Window M57. When flow direction is an issue, module 0~4~20mA is available. When the flow direction displays as negative, the current output is in range of 0~4mA, whereas the 4~20mA is for the positive direction. The output module options are displayed in Window M55. Enter “-1000” in Window M56 and 2000 in Window M57.

Calibrating and testing the current loop is performed in Window M58. Complete the steps as follows: Press Menu 5 8 ENT , move UP or DN display “0mA”, “4mA”, “8mA”, “16mA”, “20mA” readings, connect an ammeter to test the current loop output and calculate the difference. Calibrate it if the difference is within tolerance. If not, how to calibrate the current loop is to be found in *Section 5.11* in this chapter.

Check the present current loop output in Window M59 as it changes along with change in flow.

5.7. Frequency Output

The flow meter is provided with a frequency output transmitter function. The high or low frequency output displayed indicates the high or low flow rate reading. The user can reset the frequency output as well as flow rate per his requirements For example: if a pipe flow range is 0~3000m³/h, the relative frequency output required is 123~1000Hz, and the configuration is as follows:

In Window M68 (low limit frequency output flow value), input 0;

In Window M69 (high limit frequency output flow value), input 3000;

In Window M67 (low limit frequency), input 123

There is no output circuit specially assigned to frequency output. It only can be transmitted through OCT, i.e. select Window M78 (item "09. POS Int Pulse").

5.8. Totalizer Pulse Output

Each time the flowmeter reaches a unit flow, it may generate a totalizer pulse output to a remote counter. To configure the unit flow, please refer to Windows M32 and M33.

The totalizer pulse output can be transmitted through OCT or a relay. So, it is necessary to configure OCT and the relay accordingly. (Please refer to Window M78 and M79).

For example, if it is necessary to transmit the positive totalizer pulse through a relay, and each pulse represents a flow of 0.1m³, ; the configuration is as follows:

In Window M33, select totalizer the flow unit "Cubic Meters (m³)";

In Window M34, select the scale factor "x0.1";

In Window M79, select "9. Positive totalizer pulse output"



ATTENTION

Make sure to select a suitable totalizer pulse, since the output may be extended if it is too large. If it is too small, the relay may activate too frequently and may probably shorten its life. Furthermore, if it operates too fast, it may generate a pulse loss error. Therefore, a rate of 1~60/minute is recommended.

5.9. Alarm Programming

The flow meter has two programmable alarms: audible alarm and on off output alarm. The audible alarm generates an internal beeper. Select the BEEPER trigger in Window M77. The on-off output alarm is generated through OCT or transmission to an external circuit by opening or closing a relay.

The on-off output signal is activated under the following conditions:

- (1) Signal not detected
- (2) Poor signal detected
- (3) The flow meter is not ready for normal measurement
- (4) The flow is in the reverse direction (back flow)
- (5) The analog outputs exceed span by 120%
- (6) The frequency output exceeds span by 120%
- (7) The flow rate exceeds the ranges configured (Configure the flow ranges using the software alarm system. There are two software alarms: Alarm#1 and Alarm #2. The lower limit value for

Alarm#1 is configured in Window M73, and the upper limit value is configured in Window M74.
As for Alarm#2, the lower limit value is in M75 and the upper one is in Window M76).

Example 1: To program audible alarm, activated when the flow meter is not ready for normal measurement:

Select item 2 in Window M77: "2. NO*R".

Example 2: To program the relay output alarm, activated when flow rate exceeds 300~1000m³/h:

- (1) In Window M73, input 300
- (2) In Window M74, input 1000
- (3) In Window M79, select item 6: "6. Alarm #1 limit exceed"

Example 3: To program OCT output alarm signal, activated when flow rate exceeds 100~500m³/h;
relay output alarm signal activated when flow rate exceeds 600~1000m³/h:

- (1) In Window M73, input 100
- (2) In Window M74, input 500
- (3) In Window M75, input 600
- (4) In Window M76, input 1000
- (5) In Window M78, select item 6: "6. Alarm #1"
- (6) In Window M79, select item 7: "7. Alarm #2"

5.10. Batch Controller Paragraph format change

The batch controller is able to perform flow quantity control, or the batching of specific volumes to control events in product production or chemical dosing, etc. The internal batch controller in the flow meter is able to take the high or low end of analog input signals as an input, or through the keypad, to perform control functions. The output can be transmitted through OCT or a relay.

When taking analog inputs as control signals, input an analog output which is over 2mA through the analog input terminal to indicate the condition of "1"; current "0" indicates the condition of "0".

In Window M78(OCT output), M79(relay output) or M80(Flow Batch CTRL), select Item 8 "Batch controller" and the OCT or relay output will generate output signals. Enter the batch value in Window M81. Start the batch controller after that. For details, please refer to "Windows Display Explanations".

5.11. Analog Output Calibration

The hardware detect window must be activated prior to calibration. The procedure is as follows:

1. Press Menu DN 0 ENT enter password "4213068", then press ENT to activate the detect menu. With no effect to next power on, this window will close automatically as soon as the power is turned off.
2. Press Menu DN 0 ENT to calibrate the current loop 4mA output. Use an ammeter to measure the current loop output current. At the same time, move UP or DN to adjust the displayed numbers. Watch the ammeter until it reads 4.00. Stop at this point, the 4mA has been calibrated.
3. Then, press ENT to calibrate the current loop 20mA output. The method is as same as in 4mA calibration.
4. The result is saved in EEPROM(MENU 26). Switch off the power supply has not lost.



ATTENTION

Each flow meter has been calibrated strictly before leaving factory. It is unnecessary to carry through this step except when the current value (detected while calibrating the current loop) displayed in Window M58 is not identical with the actual output current value.

6. Windows Display Explanations

6.1. Windows Display Codes








Flow Totalizer Display		33	Total Multiplier
00	Flow Rate/Net Totalizer	34	NET Totalizer
01	Flow Rate/Velocity	35	Positive Totalizer
02	Flow Rate/POS Totalizer	36	Negative Totalizer
03	Flow Rate/NEG Totalizer	37	Totalize Reset
04	Date Time/Flow Rate	38	Manual Totalizer
05	Instantaneous Caloric/Totalized Caloric	Setup Options	
06	Analog Input AI1, AI2	40	Damping Coefficient
08	System Error Codes	41	Low Flow Cutoff
09	Net Flow Today	42	Static Set Zero
Initial Parameter setup		43	Reset Static Zero
10	10 Pipe Outer Perimeter	44	Manual Zero Point Setup
11	Pipe Outer Diameter	45	Scale Factor
12	Pipe Wall Thickness	46	Network IDN
13	Pipe Inner Diameter	47	System Lock Code
14	Pipe Material	48	Entry to Calibration Data
15	Pipe Sound Velocity	Input and Output setup	
16	Liner Material	55	Current Output Selection
17	Liner Sound Velocity	56	4mA or 0mA Output Value
18	Liner Thickness	57	20 mA Output Value
20	Fluid Type	58	Current Loop Check up
21	Fluid Sound Velocity	59	Current Loop Output value
22	Fluid Viscosity	60	Date and Time Setup
23	Transducer Type	61	Software Version
24	Transducer Mounting	63	Select Comm Protocol
25	Transducer Spacing	67	Frequency Output signal Frequency Range
26	Parameter Setups	68	Flow Value of Low Frequency Output
27	Cross-sectional Area	69	Flow Value of High Frequency Output
28	Holding with Poor Sig	70	LCD Backlight Controller
29	Empty Pipe Setup	71	LCD Contrast Controller
Flow Units Options		72	Working Timer
30	Metric and English	73	Alarm #1 Low Value Set
31	Flow Rate Unit Selection	74	Alarm #1 High Value Set
32	Totalize Units	75	Alarm #2 Low Value Set







76	Alarm #2 High Value Set
77	Buzzer Setup
78	OCT Output Setup
79	RELAY Output Setup
80	Batch Trigger Select
81	Flow Batch Controller
82	Date Totalizer
83	Automatic Amending
Diagnostics menu	
90	Strength & Quality of Signal
91	Ratio of Transfer time
92	Fluid Sound Velocity
93	Total Time and Delta Time
94	Reynolds Number

Appendix	
+0	Power ON/OFF Time
+1	Total Working Hours
+2	Last Power OFF Time
+3	Last Flow Rate
+4	ON/OFF Times
+5	Calculator
+6	Media Vel. Threshold
+7	Total Flow for Month
+8	Total Flow This Year
+9	No-Ready Timer
-0	Hardware Adjusting

6.2. Display Explanation

While reading this section, please compare it with the instrument in order to improve your understanding.

<p>Menu 0 0</p> <p>Flow Rate / Net Totalizer</p> <p>Display flow rate and net totalizer.</p> <p>If the net totalizer has been turned off (refer to M34), the net totalizer value displayed is the total prior to its turn off.</p>	
<p>Menu 0 1</p> <p>Flow Rate / Velocity</p> <p>Display flow rate and velocity.</p>	
<p>Menu 0 2</p> <p>Flow Rate / Positive Totalizer</p> <p>Display flow rate and positive totalizer. Select the positive totalizer units in Window M31. If the positive totalizer has been turned off, the positive totalizer value displayed is the total prior to its turn off.</p>	
<p>Menu 0 3</p> <p>Flow Rate / Negative Totalizer</p> <p>Display flow rate and negative totalizer. Select the negative totalizer value in Window M31. If the negative totalizer has been turned off (refer to M36), the value displayed is the total prior to turn off.</p>	
<p>Menu 0 4</p> <p>Date Time / Flow Rate</p> <p>Display the current date time and flow rate.</p> <p>The time setting method is found in Window M60.</p>	
<p>Menu 0 5</p> <p>Caloric / Totalized Caloric</p> <p>Display Instantaneous Caloric and Totalized Caloric.</p>	
<p>Menu 0 6</p> <p>Analog Input Value</p> <p>Display Analog Input AI1, AI2 current value and corresponding temperature value.</p>	

<p>Menu 0 8</p> <p>System Error Codes</p> <p>Display the working condition and the system error codes. More than one error code can occur at the same time.</p> <p>The explanations of error codes and detailed resolution methods</p>	
<p>Menu 0 9</p> <p>Net Flow Today</p> <p>Display net total flow today.</p>	
<p>Menu 1 0</p> <p>Pipe Outer Perimeter</p> <p>Enter the pipe outer perimeter. If the diameter of the know, enter it in window M11.</p>	
<p>Menu 1 1</p> <p>Pipe Outer Diameter</p> <p>Enter the pipe outside diameter, The pipe outside diameter must range from 10mm to 6000mm.</p>	
<p>Menu 1 2</p> <p>Pipe Wall Thickness</p> <p>Enter the pipe wall thickness. If the pipe inside diameter is already known, skip this window and enter it in Window M13.</p>	
<p>Menu 1 3</p> <p>Pipe Inner Diameter</p> <p>Enter the pipe inside diameter. If the pipe outside diameter and pipe wall thickness has been entered, press DN to skip this window.</p> <p>Note: Enter either pipe wall thickness or pipe inside diameter.</p>	

<p>Menu 1 4</p> <p>Pipe Material</p> <p>Enter pipe material. The following options are available (by UP, DN buttons or numerical keys):</p> <table border="1" data-bbox="268 405 917 651"> <tr> <td>0. Carbon Steel</td> <td>1. Stainless Steel</td> </tr> <tr> <td>2. Cast Iron</td> <td>3. Ductile Iron</td> </tr> <tr> <td>4. Copper</td> <td>5. PVC</td> </tr> <tr> <td>6. Aluminum</td> <td>7. Asbestos</td> </tr> <tr> <td>8. Fiber Glass-Epoxy</td> <td>9. Other</td> </tr> </table> <p>Refer to item 9 “Other”; it is possible to enter other materials, which are not included in previous eight items. Once item 9 is selected, the relevant pipe sound velocity must be entered in Window M15.</p>	0. Carbon Steel	1. Stainless Steel	2. Cast Iron	3. Ductile Iron	4. Copper	5. PVC	6. Aluminum	7. Asbestos	8. Fiber Glass-Epoxy	9. Other	<table border="1" data-bbox="943 219 1410 353"> <tr> <td>Pipe Material</td> <td>[14]</td> </tr> <tr> <td>5. PVC</td> <td></td> </tr> </table>	Pipe Material	[14]	5. PVC			
0. Carbon Steel	1. Stainless Steel																
2. Cast Iron	3. Ductile Iron																
4. Copper	5. PVC																
6. Aluminum	7. Asbestos																
8. Fiber Glass-Epoxy	9. Other																
Pipe Material	[14]																
5. PVC																	
<p>Menu 1 5</p> <p>Pipe Sound Velocity</p> <p>Enter pipe sound velocity. This function is only used when item 9 “Other” is selected in Window M14. At the same time, this window cannot be visited. System will calculate automatically according to the existing parameters.</p>	<table border="1" data-bbox="943 949 1410 1084"> <tr> <td>Pipe Sound Velocity</td> <td>3604 m/s</td> </tr> </table>	Pipe Sound Velocity	3604 m/s														
Pipe Sound Velocity	3604 m/s																
<p>Menu 1 6</p> <p>Select the Liner Material</p> <p>The following options are available:</p> <table border="1" data-bbox="268 1373 917 1664"> <tr> <td>0. None ,No Liner</td> <td>1. Tar Epoxy</td> </tr> <tr> <td>2. Rubber</td> <td>3. Mortar</td> </tr> <tr> <td>4. Polypropylene</td> <td>5. Polystyrol</td> </tr> <tr> <td>6. Polystyrene</td> <td>7. Polyester</td> </tr> <tr> <td>8. Polyethylene</td> <td>9. Ebonite</td> </tr> <tr> <td>10. Teflon</td> <td>11. Other</td> </tr> </table> <p>Item 11 “Other” is available to enter other materials that are not included in previous ten items. Once the “Other” is selected, the relevant liner sound velocity must be entered in Window M17.</p>	0. None ,No Liner	1. Tar Epoxy	2. Rubber	3. Mortar	4. Polypropylene	5. Polystyrol	6. Polystyrene	7. Polyester	8. Polyethylene	9. Ebonite	10. Teflon	11. Other	<table border="1" data-bbox="943 1240 1410 1375"> <tr> <td>Liner Material</td> <td>[16]</td> </tr> <tr> <td>0. None, No Liner</td> <td></td> </tr> </table>	Liner Material	[16]	0. None, No Liner	
0. None ,No Liner	1. Tar Epoxy																
2. Rubber	3. Mortar																
4. Polypropylene	5. Polystyrol																
6. Polystyrene	7. Polyester																
8. Polyethylene	9. Ebonite																
10. Teflon	11. Other																
Liner Material	[16]																
0. None, No Liner																	

<p>Menu 1 7</p> <p>Liner Sound Velocity</p> <p>Enter liner sound velocity. It only can be visited when item “ Other” in Window M16 is selected.</p>	<p>Liner Sound Velocity</p> <p>2505 m/s</p>																
<p>Menu 1 8</p> <p>Liner Thickness</p> <p>Enter liner thickness. It only can be visited when a definite liner is selected in Window M16.</p>	<p>Liner Thickness [18]</p> <p>10 mm</p>																
<p>Menu 2 0</p> <p>Select Fluid Type</p> <p>The following options are available:</p> <table border="1" data-bbox="268 741 917 1137"> <tr> <td>0. Water</td> <td>1. Sea Water</td> </tr> <tr> <td>2. Kerosene</td> <td>3. Gasoline</td> </tr> <tr> <td>4. Fuel Oil</td> <td>5. Crude Oil</td> </tr> <tr> <td>6. Propane (-45C)</td> <td>7. Butane (0C)</td> </tr> <tr> <td>8. Other Liquid</td> <td>9. Diesel Oil</td> </tr> <tr> <td>10. Castor Oil</td> <td>11. Peanut Oil</td> </tr> <tr> <td>12. Gasoline #90</td> <td>13. Gasoline #93</td> </tr> <tr> <td>14. Alcohol</td> <td>15. Water (125C)</td> </tr> </table> <p>“Other” refers to any fluid. The relevant sound velocity must be entered in Window M21.</p>	0. Water	1. Sea Water	2. Kerosene	3. Gasoline	4. Fuel Oil	5. Crude Oil	6. Propane (-45C)	7. Butane (0C)	8. Other Liquid	9. Diesel Oil	10. Castor Oil	11. Peanut Oil	12. Gasoline #90	13. Gasoline #93	14. Alcohol	15. Water (125C)	<p>Fluid Type [20]</p> <p>0. Water (General)</p>
0. Water	1. Sea Water																
2. Kerosene	3. Gasoline																
4. Fuel Oil	5. Crude Oil																
6. Propane (-45C)	7. Butane (0C)																
8. Other Liquid	9. Diesel Oil																
10. Castor Oil	11. Peanut Oil																
12. Gasoline #90	13. Gasoline #93																
14. Alcohol	15. Water (125C)																
<p>Menu 2 1</p> <p>Fluid Sound Velocity</p> <p>Enter the fluid sound velocity. It only can be used when item “Other” is selected in Window M20, i.e. it is unnecessary to enter all the fluids listed in Window M20.</p>	<p>Fluid Sound Velocity</p> <p>2720 m/s</p>																
<p>Menu 2 2</p> <p>Fluid Viscosity</p> <p>Enter fluid’s kinematics viscosity. It only can be used when item “Other” is selected in Window M20, i.e. it is unnecessary to enter all the fluids that listed in Window M20.</p>	<p>Fluid Viscosity [22]</p> <p>1.0038 cST</p>																

<p>Menu 2 3</p> <p>Select transducer type. Please select "0.Standard".</p> <table border="1" data-bbox="268 309 917 902"> <tr> <td>0. Standard-M</td> <td>1. Insertion Type C</td> </tr> <tr> <td>2. Standard-S</td> <td>3. User Type</td> </tr> <tr> <td>4. Standard-B</td> <td>5. Insertion B(45)</td> </tr> <tr> <td>6. Standard-L</td> <td>7. JH-Polysonics</td> </tr> <tr> <td>8. Standard-HS</td> <td>9. Standard-HM</td> </tr> <tr> <td>10. Standard-M1</td> <td>11. Standard-S1</td> </tr> <tr> <td>12. Standard-L1</td> <td>13. PI-Type</td> </tr> <tr> <td>14. FS410(FUJI)</td> <td>15. FS510(FUJI)</td> </tr> <tr> <td>16. Clamp-On TM-1</td> <td>17. Insertion TC-1</td> </tr> <tr> <td>18. Clamp-On TS-1</td> <td>19. Clamp-On TS-2</td> </tr> <tr> <td>20. Clamp-On TL-1</td> <td>21. Insertion TLC-2</td> </tr> <tr> <td>22. Clamp-On M2</td> <td>23. Clamp-On L2</td> </tr> </table>	0. Standard-M	1. Insertion Type C	2. Standard-S	3. User Type	4. Standard-B	5. Insertion B(45)	6. Standard-L	7. JH-Polysonics	8. Standard-HS	9. Standard-HM	10. Standard-M1	11. Standard-S1	12. Standard-L1	13. PI-Type	14. FS410(FUJI)	15. FS510(FUJI)	16. Clamp-On TM-1	17. Insertion TC-1	18. Clamp-On TS-1	19. Clamp-On TS-2	20. Clamp-On TL-1	21. Insertion TLC-2	22. Clamp-On M2	23. Clamp-On L2	<p>Transducer Type [23 ≥ 23. Clamp-On L2</p>
0. Standard-M	1. Insertion Type C																								
2. Standard-S	3. User Type																								
4. Standard-B	5. Insertion B(45)																								
6. Standard-L	7. JH-Polysonics																								
8. Standard-HS	9. Standard-HM																								
10. Standard-M1	11. Standard-S1																								
12. Standard-L1	13. PI-Type																								
14. FS410(FUJI)	15. FS510(FUJI)																								
16. Clamp-On TM-1	17. Insertion TC-1																								
18. Clamp-On TS-1	19. Clamp-On TS-2																								
20. Clamp-On TL-1	21. Insertion TLC-2																								
22. Clamp-On M2	23. Clamp-On L2																								
<p>Menu 2 4</p> <p>Transducer Mounting</p> <p>Four mounting methods are available:</p> <ul style="list-style-type: none"> 0. V (sound wave bounces 2 times) 1. Z(sound wave bounces once. The most commonly use method) 2. N (small pipe, sound wave bounces 3 times.) 3. W (small pipe, sound wave bounces 4times.) 	<p>Transducer Mounting 0. V</p>																								
<p>Menu 2 5</p> <p>Transducer Spacing (this value is Calculated by the flow meter) The operator must mount the transducer according to the transducer spacing displayed (be sure that the transducer spacing must be measured precisely during installation). The system will display the data automatically after the pipe parameter had been entered.</p>	<p>Transducer Spacing 281.871 mm</p>																								
<p>Menu 2 6</p> <p>Parameters' Save & Load</p> <p>Several types piping and specifications can be input. This method doesn't input severe piping separately, and can be selected from the M26 and measured.</p> <ul style="list-style-type: none"> 0. Use RAM Setting 1. Solidify Setting 	<p>Default Settings [26 ≥ 1. Solidify Setting</p>																								

<p>Menu 2 7</p> <p>The area of current fluid in pipe interior is represented.</p> <p>0. 15mm, PI-Type</p> <p>1. 110mm, V, PVC</p> <p>2. 12.83mm, PI-Type</p> <p>3. 219mm, Z, Carbon St</p> <p>4. 259mm, Z, Carbon St</p> <p>5. 325mm, V, PVC</p> <p>6. 80mm, V, Carbon Ste</p> <p>7. 25mm, V, Stainless</p> <p>8. 400mm, V, PVC</p>	<p>Save/Load Parameters</p> <p>0 : 15mm, PI-Type</p>
<p>Menu 2 8</p> <p>Holding with Poor Sig</p> <p>Select "Yes" to hold last good flow signal displayed if the flow meter experiences a poor signal condition.</p> <p>This function will allow continued data calculation without interruption.</p>	<p>Hold On Poor Signal</p> <p>YES</p>
<p>Menu 2 9</p> <p>Empty Pipe Setup</p> <p>This value is used to solve problem of empty pipe.</p> <p>When pipe is empty, flowmeter shows transmission signal as "normal working" in pipe wall.</p> <p>This function is for protect against the action of flowmeter, when pipe is empty.</p> <p>For the protection, enter 30~40 in window.</p>	<p>Empty Pipe Setup [29</p> <p>39</p>
<p>Menu 3 0</p> <p>Measurement Units Options</p> <p>Select the measurement unit as follows:</p> <p>0. Metric</p> <p>1. English</p> <p>Factory default is metric.</p>	<p>Measurement Units In</p> <p>0. Metric</p>
<p>Menu 3 1</p> <p>Flow Rate Units Options</p> <p>The following flow rates units are available:</p> <p>0. Cubic Meters (m3)</p> <p>1. Liters (l)</p> <p>2. USA Gallons (Gal)</p> <p>3. UK Gallons (IGL)</p> <p>4. Million US Gallons (mg)</p> <p>5. Cubic Feet (cf)</p> <p>6. USA Oil Barrels (OB)</p> <p>7. UK Oil Barrels (IB)</p>	<p>Flow : Unit/Time</p> <p>>Cubic Meter (m3)</p> <p>Cubic Meter (m3)</p> <p>≥ /hour</p> <p>Flow Rate Unit [31</p> <p>m3/h</p>

<p>The following time units are available: / Day / Hour / Min / Sec Factory default is Cubic Meters/hour</p>	
<p>Menu 3 2 Totalizer Units Options Select totalizer units. The available unit options are as same as those found in Window M31. The user can select units as their required. Factory default is Cubic Meters.</p>	<p>Totalizer Units [31] >Cubic Meter (m3)</p>
<p>Menu 3 3 Totalizer Multiplier Options The totalizer multiplier acts as the function to increase the totalizer indicating range. Meanwhile, the totalizer multiplier can be applied to the positive totalizer, negative totalizer and net totalizer at the same time. The following options are available: 0. X0.001(1E-3) 1. X0.01 2. X0.1 3. X1 4. X10 5. X100 6. X1000 7. X10000(1E+4) Factory default factor is x1</p>	<p>Totalizer Multiplier 3. x1</p>
<p>Menu 3 4 ON/OFF Net Totalizer “ON” indicates the totalizer is turned on, while “OFF” indicates it is turned off. When it is turned off, the net totalizer displays in Window M00 will not change. Factory default is “ON”.</p>	<p>NET Totalizer [34] ON</p>
<p>Menu 3 5 ON/OFF POS Totalizer On/off positive totalizer. “ON” indicates the flowmeter starts to totalize the value. When it is turned off, the positive totalizer displays in Window M02. Factory default is “ON”.</p>	<p>POS Totalizer [35] ON</p>
<p>Menu 3 6 ON/OFF NEG Totalizer ON/OFF negative totalizer. “ON” indicates the totalizer is turned on. When it is turned off, the negative totalizer displays in Window M03. Factory default is “ON”.</p>	<p>NEG Totalizer [36] ON</p>

<p>Menu 3 7</p> <p>Totalizer Reset</p> <p>Totalizer reset will make all parameters are reset.</p> <p>Press ENT ; move UP or DN arrow to select “YES” or “NO”.</p> <p>After “YES” is selected, the following options are available: None, All, NET, POS, NEG If it is necessary to recover the factory default, press keys after the above-mentioned characters are displayed on the screen. Generally, it is unnecessary to activate this function except during the initial installation.</p>	<div style="border: 2px solid yellow; padding: 5px; text-align: center;"> <p>Totalizer Reset? [37]</p> <p>Selection</p> </div>
<p>Menu 3 8</p> <p>Manual Totalizer</p> <p>The manual totalizer is a separate totalizer. Press ENT to start, and press ENT to stop it. It is used for flow measurement and calculation.</p>	<div style="border: 2px solid yellow; padding: 5px; text-align: center;"> <p>Manual Totalizer [38]</p> <p>Press ENT When Ready</p> </div>
<p>Menu 4 0</p> <p>The damping function will stabilize the flow display.</p> <p>Essentially, it is a part of the signal filter. Enter a coefficient.</p> <p>Increasing the coefficient increases the stability. However, the measurement displayed may be slightly delayed due to over damping. Logging too long may result in no response to real-time fluctuation, especially when flow rate fluctuates wildly. Therefore, damping should be kept at a minimum and increased just enough to reduce the fluctuation to an acceptable degree by 3 to 10 seconds. indicates no damping; 999 indicate the maximum damping. Usually a damping factor of 3 to 10 is recommend in applications.</p>	<div style="border: 2px solid yellow; padding: 5px; text-align: center;"> <p>Damping [40]</p> <p>3 sec</p> </div>
<p>Menu 4 1</p> <p>Low Flow Cutoff Value</p> <p>If the flow rate falls below the low flow cutoff value, the flow indication is driven to zero. This function can prevent the flow meter from reading flow after a pump as shut down but there is still liquid movement in the pipe, which will result in totalization error. Generally, 0.03m/s is recommended to enter as the low flow cutoff point. The low flow cutoff value has no relation to the measurement results once the velocity increases over the low flow cutoff value</p>	<div style="border: 2px solid yellow; padding: 5px; text-align: center;"> <p>Low Flow Cutoff Val.</p> <p>0.03 m/s</p> </div>

<p>Menu 4 2</p> <p>Set Zero</p> <p>When fluid is in the static state, the displayed value is called "Zero Point". When "Zero Point" is not at zero in the flow meter, the difference is going to be added into the actual flow values and measurement differences will occur in the flow meter. Set zero must be carried out after the transducers are installed and the flow inside the pipe is in the absolute static state (no liquid movement in the pipe). Thus, the "Zero Point" resulting from different pipe mounting locations and parameters can be eliminated. The measuring accuracy at low flow is enhanced by doing this and flow offset is eliminated. Press ENT , wait for the processing instructions at the bottom right corner to reach 0. Performing Set zero with existing flow may cause the flow to be displayed as "0". If so, it can be recovered via Window M43.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Set Zero [42]</p> <p>Press ENT to go</p> </div>
<p>Menu 4 3</p> <p>Reset Zero</p> <p>Select "YES"; reset "Zero Point" which was set by the user.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Reset Zero [43]</p> <p>NO</p> </div>
<p>Menu 4 4</p> <p>Manual Zero Point</p> <p>This method is not commonly used. <i>It is only suitable for experienced operators to set zero under conditions when it is not preferable to use other methods.</i> Enter the value manually to add to the measured value to obtain the actual value. For example:</p> <p>Actual measured value =250 m3/h</p> <p>Value Deviation =-10 m3/h</p> <p>Flowmeter Display =240 m3/h</p> <p>Normally, set the value as "0".</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Manual Zero Point [44]</p> <p>0 m3/h</p> </div>
<p>Menu 4 5</p> <p>Scale Factor</p> <p>The scale factor is used to modify the measurement results. The user can enter a numerical value other than "1" according to calibration results.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Scale Factor [45]</p> <p>1.034</p> </div>





<p>Menu 4 6</p> <p>Network IDN</p> <p>Input system identifying code, these numbers can be selected from 0~65535 except that 13 (ODH ENTER), 10 (0AH Newline), 42 (2AH *) and 38 (26H&) are reserved. System IDN is used to identify the flow meter to a network.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Network IDN [46]</p> <p>1</p> </div>
<p>Menu 4 7</p> <p>System Lock</p> <p>Lock the instrument.</p> <p>Once the system is locked, any modification to the system is prohibited, but the parameter is readable.</p> <p>“Unlock” using your designated password. The password is composed of 1 to 4 numbers.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>System Lock [47]</p> <p>**** Unlocked ****</p> </div>
<p>Menu 54</p> <p>OCT Pulse Width</p> <p>Max. 500 mS</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>OCT Pulse Width [54]</p> <p>199.432 mS</p> </div>
<p>Menu 5 5</p> <p>Current Loop Mode Select</p> <p>Select the current loop mode. The following options are available:</p> <ul style="list-style-type: none"> 0. 4-20 mA 5. 0-4-20 mA 1. 0-20 mA 6. 20-0-20 mA 2. 0-20mA Via RS232 7. 4-20mA vs, Vel. 3. 4-20 mA vs. Sound 8. 4-20mA vs, Energy 4. 20-4-20 mA 	<div style="border: 2px solid yellow; padding: 5px;"> <p>CL Mode Select [55]</p> <p>0. 4 – 20 mA</p> </div>
<p>Menu 5 6</p> <p>CL 4mA or 0mA Output Value</p> <p>Set the CL output value according to the flow value at 4mA or 0mA.(4mA or 0mA are determined by the settings in Window M56). The flow unit’s options are as same as those in Window M31. Once “velocity 4-20mA”is selected in Window M56, the unit should be set as m/s.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>CL 4mA Output Value</p> <p>0 m3/h</p> </div>
<p>Menu 5 7</p> <p>20mA Output Value</p> <p>Set the CL output value according to the flow value at 20mA. The flow unit is the same as that found in Window M31.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>CL 20mA Output Value</p> <p>300 m3/h</p> </div>

<p>Menu 5 8</p> <p>CL Check Verification</p> <p>Check if the current loop has been calibrated before leaving the factory. Press ENT move UP or DN separately to display 0mA, 4mA till 24mA, and at the same time, check with an ammeter to verify that CL output terminals M31 and 32 agree with the displayed values. It is necessary to re-calibrate the CL if over the permitted tolerance. For more information, refer to “Analog Outputs Calibration”.</p> <p>“0”, “4”, “8”, “12”, “16”, “20” mA</p>	<div data-bbox="943 219 1407 353" style="border: 2px solid yellow; padding: 5px;"> <p>CL Checkup (mA) [58 Press ENT When Ready</p> </div> <div data-bbox="943 365 1407 499" style="border: 2px solid yellow; padding: 5px;"> <p>CL Checkup (mA) [58 ➤ 4</p> </div>
<p>Menu 5 9</p> <p>CL Current Output</p> <p>Display CL current output. The display of 10.0000mA indicates that CL current output value is 10.0000mA.</p> <p>If the difference between displaying value and CL output value is too large, the current loop then needs to be re-calibrated accordingly.</p>	<div data-bbox="943 701 1407 835" style="border: 2px solid yellow; padding: 5px;"> <p>CL Current Output [59 4.000 mA</p> </div>
<p>Menu 6 0</p> <p>Date and Time Settings</p> <p>Generally, it is unnecessary to modify date time as the system is provided with a highly reliable perpetual calendar chip. The format for setting time setting is 24 hours.</p> <p>Press ENT , wait until “>” appears, the modification can be made.</p>	<div data-bbox="943 1037 1407 1171" style="border: 2px solid yellow; padding: 5px;"> <p>YY-MM-DD HH:MM:SS 13-06-22 12:06:40</p> </div>
<p>Menu 6 1</p> <p>ESN</p> <p>Display electronic Model and serial number (ESN) of the instrument. This ESN is the only one assigned to each flowmeter ready to leave the factory. The factory uses it for files setup and for management by the user.</p>	<div data-bbox="943 1373 1407 1507" style="border: 2px solid yellow; padding: 5px;"> <p>FUM-1000 Ver18.42 S/N=18217291</p> </div>
<p>Menu 6 2</p> <p>COM Setup</p> <p>COM Setup is the window used to set serial port; the Serial port for communications and other equipment.</p> <p>Its connection with the equipment of its serial port set of parameters must match. Window the first choice of data that baud rate, 9600,19200,38400,56000,57600,115200 choice.</p> <p>The second option that in check, None.</p>	<div data-bbox="943 1664 1407 1798" style="border: 2px solid yellow; padding: 5px;"> <p>RS-485/RS-232 Setup 9600, None, 8,1</p> </div>

<p>Data length fixed to eight; Stop bit for a fixed length; Factory serial port parameters for the default "9600, 8, None, 1".</p>	
<p>Menu 6 3 Select Comm Protocol MODBUS ASCII+TDS7 MODBUS RTU Only</p>	<p>Select Comm Protocol >MODBUS RTU Only</p>
<p>Menu 6 7 Set FO Frequency Range Set up low FO Frequency and high FO frequency range. It must be higher than the low FO frequency. Ranges from 1-999Hz. Factory default is 1000Hz. NOTE: The frequency output is transmitted through OCT Serial Port; therefore the OCT must be set to the frequency output mode.</p>	<p>FO Frequency Range 0 -> 1000 Hz</p>
<p>Menu 6 8 Low FO Flow Rate Set up low FO flow rate, i.e. the corresponding flow value when output signal frequency is at the lowest FO frequency. For example, when the low FO frequency is 1000Hz, low FO flow rate is 100m3/h (when the frequency output is 1000Hz, then the low flow at this moment measured by the flow meter is 100m3/h.</p>	<p>Low FO Flow Rate [68 0 m3/h</p>
<p>Menu 6 9 High FO Flow Rate Enter the high FO flow rate, i.e. the corresponding flow value when frequency output signal is at highest FO frequency.</p>	<p>High FO Flow Rate [68 100 m3/h</p>
<p>Menu 7 0 LCD Backlit Option Select LCD backlit controls. For example, If the user enter "10", the backlighting will keep on for "10" seconds then turn off automatically.</p>	<p>LCD Backlight Option 10 Sec</p>

<p>Menu 7 2</p> <p>Working Timer</p> <p>Display the totalized working hours of the flow meter since last reset. It is displayed by HH:MM:SS. If it is necessary to reset it, press ENT , and select "YES".</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Working Timer [72]</p> <p>12345678:36:21</p> </div>																										
<p>Menu 7 8</p> <p>OCT Output Setup</p> <p>The OCT output in the flow meter is a kind of isolated collector open circuit output with programmable open and close qualifications. The user can program the open and close functions under the following conditions: the system alarm signals are being activated or the totalizer pulse is being transmitted.</p> <p>The frequency output signal is also transmitted from the OCT. When it functions as the frequency output, other functions are unavailable The following signal options are available:</p> <table border="1" data-bbox="268 1025 917 1666"> <tr> <td>0. No Signal</td> <td>1. Poor Signal</td> </tr> <tr> <td>2. Not Ready (No*R)</td> <td>3. Reverse Flow</td> </tr> <tr> <td>4. AO Over 100%</td> <td>5. FO Over 120%</td> </tr> <tr> <td>6. Alarm #1</td> <td>7. Reverse Alarm #2</td> </tr> <tr> <td>8. Batch Controller</td> <td>9. POS Int Pulse</td> </tr> <tr> <td>10. NEG Int Pulse</td> <td>11. NET Int Pulse</td> </tr> <tr> <td>12. Energy POS Pulse</td> <td>13. Energy NEG Pulse</td> </tr> <tr> <td>14. Energy NEG Pulse</td> <td>15. MediaVel=>Thresh</td> </tr> <tr> <td>16. MediaVel<Thresh</td> <td>17. ON/OFF via RS485</td> </tr> <tr> <td>18. Timer(M51 Daily)</td> <td>19. Timed Alarm #1</td> </tr> <tr> <td>20. Timed Alarm #2</td> <td>21. Batch Total Full</td> </tr> <tr> <td>22. Timer by M51</td> <td>23. Batch 90% Full</td> </tr> <tr> <td>24. Flow Rate Pulse</td> <td>25. Disable OCT</td> </tr> </table>	0. No Signal	1. Poor Signal	2. Not Ready (No*R)	3. Reverse Flow	4. AO Over 100%	5. FO Over 120%	6. Alarm #1	7. Reverse Alarm #2	8. Batch Controller	9. POS Int Pulse	10. NEG Int Pulse	11. NET Int Pulse	12. Energy POS Pulse	13. Energy NEG Pulse	14. Energy NEG Pulse	15. MediaVel=>Thresh	16. MediaVel<Thresh	17. ON/OFF via RS485	18. Timer(M51 Daily)	19. Timed Alarm #1	20. Timed Alarm #2	21. Batch Total Full	22. Timer by M51	23. Batch 90% Full	24. Flow Rate Pulse	25. Disable OCT	<div style="border: 2px solid yellow; padding: 5px;"> <p>OCT Output Setup [78]</p> <p>0. No Signal</p> </div>
0. No Signal	1. Poor Signal																										
2. Not Ready (No*R)	3. Reverse Flow																										
4. AO Over 100%	5. FO Over 120%																										
6. Alarm #1	7. Reverse Alarm #2																										
8. Batch Controller	9. POS Int Pulse																										
10. NEG Int Pulse	11. NET Int Pulse																										
12. Energy POS Pulse	13. Energy NEG Pulse																										
14. Energy NEG Pulse	15. MediaVel=>Thresh																										
16. MediaVel<Thresh	17. ON/OFF via RS485																										
18. Timer(M51 Daily)	19. Timed Alarm #1																										
20. Timed Alarm #2	21. Batch Total Full																										
22. Timer by M51	23. Batch 90% Full																										
24. Flow Rate Pulse	25. Disable OCT																										

<p>Menu 7 9</p> <p>Relay Output Setup</p> <p>The relay output in the flow meter is programmable.</p> <p>The user can program the open and close functions under the following conditions: the system alarm signals are activated or the totalizer pulse is transmitting. The relay is single-pole and constant-on for external instrument controls.</p> <p>The following options are available:</p> <table border="1" data-bbox="268 593 917 1187"> <tr> <td>1. No Signal</td> <td>2. Poor Signal</td> </tr> <tr> <td>3. Not Ready (No*R)</td> <td>4. Reverse Flow</td> </tr> <tr> <td>5. AO Over 100%</td> <td>6. Alarm #1</td> </tr> <tr> <td>7. Reverse Alarm #2</td> <td>8. Batch Controller</td> </tr> <tr> <td>9. POS Int Pulse</td> <td>10. NEG Int Pulse</td> </tr> <tr> <td>11. NET Int Pulse</td> <td>12. Energy POS Pulse</td> </tr> <tr> <td>13. Energy NEG Pulse</td> <td>14. Energy NEG Pulse</td> </tr> <tr> <td>15. MediaVel=>Thresh</td> <td>16. MediaVel<Thresh</td> </tr> <tr> <td>17. ON/OFF via RS485</td> <td>18. Timer(M51 Daily)</td> </tr> <tr> <td>19. Timed Alarm #1</td> <td>20. Timed Alarm #2</td> </tr> <tr> <td>21. Batch Total Full</td> <td>22. Timer by M51</td> </tr> <tr> <td>23. Batch 90% Full</td> <td>24. Disable Relay</td> </tr> </table>	1. No Signal	2. Poor Signal	3. Not Ready (No*R)	4. Reverse Flow	5. AO Over 100%	6. Alarm #1	7. Reverse Alarm #2	8. Batch Controller	9. POS Int Pulse	10. NEG Int Pulse	11. NET Int Pulse	12. Energy POS Pulse	13. Energy NEG Pulse	14. Energy NEG Pulse	15. MediaVel=>Thresh	16. MediaVel<Thresh	17. ON/OFF via RS485	18. Timer(M51 Daily)	19. Timed Alarm #1	20. Timed Alarm #2	21. Batch Total Full	22. Timer by M51	23. Batch 90% Full	24. Disable Relay	<table border="1" data-bbox="949 212 1412 347"> <tr> <td style="background-color: yellow;"> RELAY Output Setup [79] 0. No Signal </td> </tr> </table>	RELAY Output Setup [79] 0. No Signal
1. No Signal	2. Poor Signal																									
3. Not Ready (No*R)	4. Reverse Flow																									
5. AO Over 100%	6. Alarm #1																									
7. Reverse Alarm #2	8. Batch Controller																									
9. POS Int Pulse	10. NEG Int Pulse																									
11. NET Int Pulse	12. Energy POS Pulse																									
13. Energy NEG Pulse	14. Energy NEG Pulse																									
15. MediaVel=>Thresh	16. MediaVel<Thresh																									
17. ON/OFF via RS485	18. Timer(M51 Daily)																									
19. Timed Alarm #1	20. Timed Alarm #2																									
21. Batch Total Full	22. Timer by M51																									
23. Batch 90% Full	24. Disable Relay																									
RELAY Output Setup [79] 0. No Signal																										
<p>Menu 8 0</p> <p>Flow Batch CTRL</p> <p>The choice of quantitative window of the launch control signal controller. The following options are available:</p> <table border="1" data-bbox="268 1422 917 1668"> <tr> <td>0. Key Pressing</td> <td>1. Serial Port</td> </tr> <tr> <td>2. AI3 Rising Edge</td> <td>3. AI3 Falling Edge</td> </tr> <tr> <td>4. AI4 Rising Edge</td> <td>5. AI4 Falling Edge</td> </tr> <tr> <td>6. AI5 Rising Edge</td> <td>7. AI5 Falling Edge</td> </tr> <tr> <td>8. Timer-Periodical</td> <td>9. Timer-daily</td> </tr> </table>	0. Key Pressing	1. Serial Port	2. AI3 Rising Edge	3. AI3 Falling Edge	4. AI4 Rising Edge	5. AI4 Falling Edge	6. AI5 Rising Edge	7. AI5 Falling Edge	8. Timer-Periodical	9. Timer-daily	<table border="1" data-bbox="949 1243 1412 1377"> <tr> <td style="background-color: yellow;"> Batch Trigger Select 0. Key Pressing </td> </tr> </table>	Batch Trigger Select 0. Key Pressing														
0. Key Pressing	1. Serial Port																									
2. AI3 Rising Edge	3. AI3 Falling Edge																									
4. AI4 Rising Edge	5. AI4 Falling Edge																									
6. AI5 Rising Edge	7. AI5 Falling Edge																									
8. Timer-Periodical	9. Timer-daily																									
Batch Trigger Select 0. Key Pressing																										

<p>Menu 8 1</p> <p>Flow Batch Controller</p> <p>The internal batch controller in the flow meter is able to control the input signals through keypad or analog input Serial Port. Output signals can be transmitted through OCT or relay. The flow batch value can be modified in this window. The screen will enter the batch control display as soon as the modification completed.</p>	
<p>Menu 8 2</p> <p>Date Totalizer</p> <p>It is possible to review the historical flow data totalizer for any day for the last 64 days, any month for last 64 months and any year for last 5 years.</p> <ul style="list-style-type: none"> 0. Browse by Day 1. Browse by Month 2. Browse by Year 	
<p>Menu 8 3</p> <p>Automatic Flow Correction</p> <p>With the function of automatic flow correction, the flow lost in an offline session can be estimated and automatically adjusted. The estimate is based on the average value, which is obtained from flow rate before going offline and flow measured after going online the next time, multiplied times the time period that the meter was offline. Select "NO" to cancel this function.</p>	
<p>Menu 9 0</p> <p>Signal Strength and Signal Quality</p> <p>Display the measured signal strength and signal quality Q value upstream and downstream.</p> <p>Signal strength is indicated from 00.0 ~ 99.9. A reading of 00.0 indicates no signal detected, while 99.9 indicates maximum signal strength. Normally the signal strength should be ≥ 60.0. Signal quality Q is indicated by 00~99. Therefore, 00 indicates the poorest signal while 99 indicates the best signal. Normally, signal quality Q value should be better than 50.</p>	

<p>Menu 9 1</p> <p>TOM/TOS*100</p> <p>Display the ratio between the actual measured transmit time and the calculated transmit time according to customer's requirement. Normally the ratio should be 100±3%. If the difference is too large, the user should check that the parameters are entered correctly especially the sound velocity of the fluid and the installation of the transducers. This data is of no use before the system is ready.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>TOM/TOS*100 [91]</p> <p>100.0000 %</p> </div>
<p>Menu 9 2</p> <p>Fluid Sound Velocity</p> <p>Display the measured fluid sound velocity. Normally this value should be approximately equal to the entered value in Window M21. If the difference is too large, it probably results from an incorrect value entered in Window M21 or improper installation of the transducers.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Fluid Sound Velocity</p> <p>1985.45 m/s</p> </div>
<p>Menu 9 3</p> <p>Total Time and Delta Time</p> <p>Display the measured ultrasonic average time (unit: nS) and delta time of the upstream and downstream (unit: nS) time. The velocity calculation in the flow meter is based on the two readings. The delta time is the best indication that the instrument is running steadily. Normally the fluctuation in the ratio of the delta time should be lower than 20%. If it is not, it is necessary to check if the transducers are installed properly or if the parameters have been entered correctly.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>TotalTime, DeltaTime</p> <p>9.7654uS, 189.125nS</p> </div>
<p>Menu 9 4</p> <p>Reynolds Number and Factor</p> <p>Display the Reynolds number that is calculated by the flow meter and the factor that is set currently by the flow meter. Normally this scaling factor is the average of the line and surface velocity factor inside the pipe.</p>	<div style="border: 2px solid yellow; padding: 5px;"> <p>Reynolds No, Profile</p> <p>352.07 0.7500</p> </div>

<p>Menu UP 0</p> <p>Power ON/OFF Time</p> <p>To view the power on/off time and flow rate for the last 64 update times to obtain the offline time period and the corresponding flow rate. Enter the window, press ENT to display the last update before the last 64 times of on/off time and flow rate values. "ON" on right hand indicates that time power is on; "00" on the upper left corner indicates "00-07-18 12:40:12" the date time; flow rate is displayed in the lower right corner.</p>	<div data-bbox="943 219 1407 353" style="border: 2px solid yellow; padding: 5px;"> <p>Power ON/OFF Time [+0] Press ENT When Ready</p> </div> <div data-bbox="943 376 1407 510" style="border: 2px solid yellow; padding: 5px;"> <p>00 13-06-25 09:43:05 ON 00 0 m3/h</p> </div>
<p>Menu UP 1</p> <p>Total Working Hours</p> <p>With this function, it is possible to view the total working hours since the flow meter left the factory.</p> <p>The figure on the right indicates that the total working hours since the flow meter left the factory is 12345678 hours 42 minutes 45 seconds.</p>	<div data-bbox="943 696 1407 831" style="border: 2px solid yellow; padding: 5px;"> <p>Total Work Hours [+1] 12345678 : 42 : 45</p> </div>
<p>Menu UP 2</p> <p>Last Power Off Time</p> <p>Display the last power off time.</p>	<div data-bbox="943 1032 1407 1167" style="border: 2px solid yellow; padding: 5px;"> <p>Last Power Off Time 13-07-02 09 : 43 : 05</p> </div>
<p>Menu UP 3</p> <p>Last Flow Rate</p> <p>Displays the last flow rate.</p>	<div data-bbox="943 1227 1407 1361" style="border: 2px solid yellow; padding: 5px;"> <p>Last Flow Rate [+3] 123.456 m3/h</p> </div>
<p>Menu UP 4</p> <p>Total ON/OFF Times</p> <p>Display total on/off times since the flow meter left the factory.</p>	<div data-bbox="943 1422 1407 1556" style="border: 2px solid yellow; padding: 5px;"> <p>ON/OFF Time [+4] 00000027</p> </div>

7. Error Diagnoses

The ultrasonic flow meter has advanced self-diagnostics functions and displays any errors in the upper right corner of the LCD via definite codes in a date/time order. Hardware error diagnostics are usually performed each time the flow meter is powered on. Some errors can be detected during normal operation. Undetectable errors caused by incorrect settings and unsuitable measurement conditions will be displayed accordingly. This function helps to detect the errors and determine causes quickly; thus, problems can be solved in a timely manner according to the solutions listed in the following tables.

Errors displayed in the flow meter are divided into two categories:

Table 1 is for errors displayed during self-diagnostics upon powering on the flow meter. “* F” may be displayed on the upper left corner of the screen after entering the measuring mode. When this occurs, it is necessary to power on for self-diagnostics once again to detect and solve possible errors using the table below. If a problem still exists, please contact the factory or the factory’s local representative for assistance.

Table 2 applies when errors caused by incorrect settings and signals are detected and are announced by error codes displayed in Window M08.

7.1. Table 1. Self-diagnoses and Error Solutions (upon power on)

LCD Display	Cause	Solution
Rom Parity Error	System ROM illegal or error	Contact the factory
Stored Data Error	System stored data block error	Power on again or contact the factory
SCPU Fatal Error!	SCPU circuit fatal error	Power on again or contact the factory
Timer Slow Error Timer Fast Error	System clock error	Contact the factory
CPU or IRQ Error	CPU or IRQ problem	Power on again
System RAM Error	System RAM questionable	Power on again or contact the factory
Time or Bat Error	System date time chip error	Power on again or contact the factory
No Display, Erratic or Abnormal Operation	Bad wiring connection	Check wiring connections
Stroke Key - No Response	Keypad locked or bad plug connection	Enter the unlock password if the keypad is locked

7.2. Table 2. Error codes and solutions (during operation)

CODE	MO8 DISPLAY	CAUSE	SOLUTION
* R	System Normal	Systemnormal	No errors
* J	Sub CPU Fatal Error	Sub CPU defect	Connect the factory
* I	Signal not detected	Signal not detected	Attach transducer to the pipe and tighten it securely. Apply a plenty of coupling compound on transducer and pipe wall.
		Spacing is not correct between the transducers or not enough coupling compound applied to face of transducers.	Remove any rust, scale, or loose paint from the pipe surface. Clean it with a file.
		Transducers installed improperly	Check the initial parameter settings.
		Scale is too thick	Remove the scale or change the scaled pipe section. Normally, it is possible to change a measurement location. The instrument may run properly at a new site with less scale.
		New pipe liner	Wait until liners solidified and saturated.
* H	Low Signal strength	Signal strength is low	Solve as the upper
* H	Poor Signal Quality	Signal quality is poor Including all above reasons	Use corresponding solve
* Q	Frequency output over	Adjust actual flow as frequency output 120%.	Re-check the frequency output settings (refers to M66-M69 specifications) or confirm whether the actual flow quantity is too large.
* E	Current Loop Over	The value error between neighbor two measurement is over 120% , this is normal phenomenon when the flow is very small or near zero point	Re-check the settings (refers to M56 specifications) or confirm whether the actual flow quantity is too large.
* F	Refers to table1	find troubles when power is on and self-monitoring eternal hardware obstacle	Try to turn the power on again, and observe the displayed information and deal with it according to the last table. Please contact the manufacture if it still has the trouble. Contact the manufacture
* G	ADJ GAIN=> S1 ADJ GAIN=> S2 ADJ GAIN=> S3 ADJ GAIN=> S4	The setting is that adjusting did increase. If instrument stops or switch at S1, S2, the it will have signal wavelength of too low or poor.	Try concerned solution.
*K	Pipe Empty. Set in Window M29	No fluid in pipe or settings incorrect	Once fluid is detected in the pipe, set 0 in Window M29.

7.3. Frequently Asked Questions and Answers

Question: New pipe, high quality material, and all installation requirements met: Why still no signal detected?

Answer: Check pipe parameter settings, installation method and wiring connections. Confirm if the coupling compound is applied adequately, the pipe is full of liquid, transducer spacing agrees with the screen readings and the transducers are installed in the right direction.

Question: Old pipe with heavy scale inside, no signal or poor signal detected: How can it be resolved?

Answer: Check if the pipe is full of fluid. Try the **Z method** for transducer installation (If the pipe is too close to a wall, or it is necessary to install the transducers on a vertical or inclined pipe with flow upwards instead of on a horizontal pipe). Carefully select a good pipe section and fully clean it, apply a wide band of coupling compound on each transducer face (bottom) and install the transducer properly. Slowly and slightly move each transducer with respect to each other around the installation point until the maximum signal is detected. Be careful that the new installation location is free of scale inside the pipe and that the pipe is concentric (not distorted) so that the sound waves do not bounce outside of the proposed area. For pipe with thick scale inside or outside, try to clean the scale off, if it is accessible from the inside.

(Note: Sometimes this method might not work and sound wave transmission is not possible because of the a layer of scale between the transducers and pipe inside wall).

Question: Why is the CL output abnormal?

Answer: Check to see if the desired current output mode is set in Window M55. Also, check to see if the maximum and minimum current values are set properly in Windows M56 and M57. Re-calibrate CL and verify it in Window M59.

Question: Why is the flow rate still displayed as zero while there is fluid obviously inside the pipe and a symbol of "R" displayed on the screen?

Answer: Check to see if "Set Zero" was carried out with fluid flowing inside the pipe(Refer to Window M42). If it is confirmed, recover the factory default in Window M43.

Question: With a poor measurement site environment in the plant and the voltage and power supplies fluctuating widely, is the instrument really able to keep running 24 hours a day repeatedly without stopping and last for several years under such conditions?

Answer: The FUM-1000 flow meter is designed to work with high reliability under such conditions. It is provided with an intelligent signal conditioning circuit and internal correction circuitry. FUM-1000 will work under strong interference conditions and is able to adjust itself with strong or weak sound waves. It will work in a wide band of voltage: 90-245VAC or 10V~36VDC voltage.

8. Product Overview

8.1. Introduction

The FUM-1000 is a state-of-the-art universal transit-time flow meter designed using SLSI technology and low voltage broadband pulse transmission. While principally designed for clean liquid applications, the instrument is tolerant of liquids with small amounts of air bubbles or suspended solids found in most industrial environments.

8.2. Features of FUM-1000 Dedicated

With distinctive features such as high precision, high reliability, high capability and low cost, the flow meter features other advantages:


- ◆ Low consumption power, high reliability, anti-jamming and outstanding applicability.
- ◆ Clear, user-friendly menu selections make flow meter simple and convenient to use.
- ◆ U.S., British and Metric measurement units are available. Meanwhile, almost all-universal measurement units worldwide may be selected to meet customer's requirements.
- ◆ Daily, monthly and yearly totalized flow: Totalized flow for the last 64 days and months as well as for the last 5 years are may be viewed.
- ◆ Power on/off function: allows the viewing of time and flow rate as power is switched on and off 64 times. Also, the flow meter has manual or automatic amendment during offline sessions.
- ◆ Self-contained signal output, including relay, open collector, frequency and 4~20mA current loop analog outputs, etc.
- ◆ Parallel operation of positive, negative and net flow totalizes with scale factor (span) and 7 digit display, while the output of totalize pulse and frequency output are transmitted via relay and open collector.
- ◆ Internally configured batch controller makes batch control convenient.

8.3. Theory of Operation

When the ultrasonic signal is transmitted through the flowing liquid, there will be a difference between the upstream and downstream transit time (travel time or time of flight), which is proportional to flow velocity, according to the formula below.

$$T_{UP} = \frac{MD / \cos\theta}{C_o + V \sin\theta} \quad (1)$$

$$T_{DOWN} = \frac{MD / \cos\theta}{C_o - V \sin\theta} \quad (2)$$



M - Spreading times

D - inner diameter

θ - Sending in angle

C_0 - Fluid static sound velocity

T_{UP} - positive spreading time

T_{DOWN} - negative spreading time

ΔT - spreading time difference ($=T_{UP} - T_{DOWN}$)

The average velocity is gotten in pipe, when (1) and (2) are equal.

$$V = \frac{MD}{\sin 2\theta} \cdot \frac{\Delta T}{T_{UP} \times T_{DOWN}}$$

8.4. Applications

- ◆ Water, sewage (with low particle content) and seawater
- ◆ Water supply and drainage water
- ◆ Power plants (nuclear power plant, thermal and hydropower plants), heat energy, boiler feed water and energy management system
- ◆ Metallurgy and mining applications (cooling water and acid recovery, for example)
- ◆ Petroleum and chemicals
- ◆ Food, beverage and pharmaceutical
- ◆ Marine operation and maintenance
- ◆ Energy economy supervision and water conservation management
- ◆ Pulp and paper
- ◆ Pipeline leak detection
- ◆ Regular inspection, tracking and collection
- ◆ Energy measuring and balance
- ◆ Network monitoring systems and energy/flow computer management

8.5. Specifications

ITEM		CONTENTS
Pipe	Material	Steel , Stainless steel, Cast iron, Harden plastic (concrete and lining pipe need discuss)
	Inner diameter	25 ~ 6000mm
	Vertical pipe length	Confirmed straight pipe of upper stream 10D, downstream 5D Pump outlet side needs straight pipe of 30D. (reference page 13 and 14)
Fluid	Sort	Most liquid measure: Water, seawater, oil, chemical and etc
	Turbidity	Clear liquid with no air bubbles (less than 10000ppm (mg/l))
	Temperature	-20℃ ~ +80℃, (the liquid without freezing, brine)
Sensor	Velocity	0m/s ~±30m/s
	Sorts of sensor	Clamp-On S, Clamp-On M2, Clamp-On L2 Insertion Type B
	Installation method	"V" method : in general, suitable for small pipe diameters D≤350mm; "Z" method : in general, suitable for small pipe diameters D≥350mm; "W" method : D≤50mm
	Cable length	Standard: 10m, Max: 200m. Wire resistance: 75Ω
Body	Display	Digital backlight LCD of character numeric (2×20)
	Keyboard	4×4 keyboard
	Installation method	on-wall mounting in gauge room or gauge box
	Output	4 ~ 20mA or 0 ~ 20mA current loop, precision 0.1% RS-485 Output frequency range of programs : 1 ~ 9,999Hz (OCT output) Relay output
	Power supply	FUM-1000 wall-mounting type: 110VAC, 220VAC ±10% or 8~36VDC
	Power	2 Watts
	Size	FUM-1000 installation type : 251×92×80mm;
	Weight	FUM-1000 : 3.1 Kg,
Environment	Temperature	Body : -20 ~ 50℃ Sensor : -20 ~ 80℃
	Humidity	Body : 85% RH (40℃) Sensor : 98% RH (40℃) , (submersible measurement until underwater 2m depth)
Accuracy	±1.0% after Calibration Reproducibility: ±0.2%~0.5% at 0 ~ ±30m/s Linearity 0.5% Data output cycle : 500ms	
Driving Time	Subsequently	

9. Appendix1 - Flow Application Data

9.1 Fluid Sound Velocity and Viscosity

Unit : m/s

Fluid type	Sound velocity	Viscosity	Fluid type	Sound velocity	Viscosity
Water 20°C	1482	1.0	Glycerin	1923	1180
Water 50°C	1543	0.55	Gasoline	1250	0.80
Water 75°C	1554	0.39	66# gasoline	1171	
Water100°C	1543	0.29	80# gasoline	1139	
Water 125°C	1511	0.25	0# diesel oil	1385	
Water 150°C	1466	0.21	Benzene	1330	
Water 175°C	1401	0.18	Ethylbenzene	1340	
Water 200°C	1333	0.15	Toluene	1170	0.69
Water 225°C	1249	0.14	Carbon tetrachloride	938	
Water 250°C	1156	0.12	Coal oil	1420	2.3
Acetone	1190		Petroleum	1290	
Acrbinor	1121		Pine oil	1280	
Ethanol	1168		Trichloroethylene	1050	0.82
Alcohol	1440	1.5	Peanut oil	1472	
Acetophenone	1310		Eastor oil	1502	
Acetaldehyde	1180				
Glycol	1620				

9.2 Sound Velocity in Liquids

Temperature and purity matter the sound velocity greatly, to pay more attention in fact.

The follow is sound velocity in liquids 20°C purity 100% :

1200m/s	Methanol, Ethanol, Octane, Ethanoic acid, Proponent, Ethyl ether
1400m/s	Light oil, Transformer oil, Spindle oil, O-dim ethyl benzene
1600m/s	Aniline, Diethyl alcohol.
1800m/s	Glycerin

9.3 Fluid Sound Velocity and Viscosity

Substance	Form Index	Temp. (°C)	Sound Vel. (m/s)	Kinematics Viscosity (m ² /s 10 ⁻⁶)	Substance	Form Index	Temp. (°C)	Sound Vel. (m/s)	Kinematics Viscosity (m ² /s 10 ⁻⁶)
Acetic acid	CH ₃ COOH	20	1159		Cinnamaldehyde	C ₉ H ₈ O	25	1554	
Acetic anhydride	(CH ₃ CO) ₂ O	20	1180	0.769	Cinnamic aldehyde	C ₉ H ₈ O	25	1554	
Acetic acid, anhydride	(CH ₃ CO) ₂ O	20	1180	0.769	Colamine	C ₂ H ₇ NO	25	1724	
Acetonitrile	C ₂ H ₃ N	25	1290	0.441	o-cresol	C ₇ H ₈ O	20	1541	4.29 (40°C)
Ethyl acetate	C ₄ H ₈ O ₂	25	1085	0.467	m-cresol	C ₇ H ₈ O	20	1500	5.979 (40°C)
Methyl acetate	C ₃ H ₆ O ₂	25	1211	0.407	Cyanomethane	C ₂ H ₃ N	25	1290	0.441
Acetone	C ₃ H ₆ O	20	1190	0.407	Cyclohexane	C ₆ H ₁₂	20	1284	1.31 (17°C)
Acetonitrile	C ₂ H ₃ N	25	1290	0.441	Cyclohexanol	C ₆ H ₁₂ O	25	1454	0.071 (17°C)
Acetonylacetone	C ₆ H ₁₀ O ₂	25	1399		Cyclohexanone	C ₆ H ₁₀ O	25	1423	
Acetylen dichloride	C ₂ H ₂ Cl ₂	25	1015	0.400	Decane	C ₁₀ H ₂₂	25	1252	1.26 (20°C)
Acetylene tetrabromide	C ₂ H ₂ Br ₄	25	1027		1-decene	C ₁₀ H ₂₀	25	1235	
Acetylene tetrachloride	C ₂ H ₂ Cl ₄	25	1147	1.156 (15°C)	n-decylene	C ₁₀ H ₂₀	25	1235	
Ethyl alcohol	C ₂ H ₆ O	25	1207	1.396	Diacetyl	C ₄ H ₆ O ₂	25	1236	
Alkazene-13	C ₁₅ H ₂₄	25	1317		Diamylamine	C ₁₀ H ₂₃ N	25	1256	
Alkazene-25	C ₁₀ H ₁₂ Cl ₂	25	1307		1, 2-dibromo-ethane	C ₂ H ₄ Br ₂	25	995	0.79 (20°C)
2-amino-ethanol	C ₂ H ₇ NO	25	1724		trans-1, 2-dibromoethene	C ₂ H ₂ Br ₂	25	935	
2-aminotolidine	C ₇ H ₉ N	25	1618	4.394 (20°C)	Dibutyl phthalate	C ₆ H ₂₂ O ₄	25	1408	
4-aminotolidine	C ₇ H ₉ N	25	1480	1.863 (50°C)	Dichloro-t-butyl alcohol	C ₄ H ₈ Cl ₂ O	25	1304	
Ammonia	NH ₃	-33	1729	0.292	2, 3-dichlorodixane	C ₂ H ₆ Cl ₂ O ₂	25	1391	
t-amyl alcohol	C ₅ H ₁₂ O	25	1204	4.374	dichlorodifluoromethane (Freon 12)	CCl ₂ F ₂	25	774.1	
Aminobenzene	C ₆ H ₅ NO ₂	25	1639	3.63	1, 2-dichloro ethane	C ₂ H ₄ Cl ₂	25	1193	0.61
Aniline	C ₆ H ₅ NO ₂	20	1659	1.762	cis1, 2-dichloro-ethane	C ₂ H ₂ Cl ₂	25	1061	
Azine	C ₆ H ₅ N	25	1415	0.992	trans 1, 2-dichloro-ethane	C ₂ H ₂ Cl ₂	25	1010	
Benzene	C ₆ H ₆	25	1306	0.711	Dichlorofluoro-methane (Freon21)	CHCl ₂ F	0	891	
Benzol	C ₆ H ₆	25	1306	0.711	1-2-dichlorohexa-fluorocyclobutane	C ₄ Cl ₂ F ₆	25	669	
Bromine	Br ₂	25	889	0.323	1-3-dichloro-isobutane	C ₄ H ₈ Cl ₂	25	1220	
Bromobenzene	C ₆ H ₅ Br	25	1170	0.693	Dichloro methane	CH ₂ Cl ₂	25	1070	0.31
1-bromo-butane	C ₄ H ₉ Br	20	1019	0.49 (15°C)	1, 1-dichloro-1, 2, 2, 2-tetra fluoroethane	CClF ₂ -CClF ₂	25	665.3	
Bromoethane	C ₂ H ₅ Br	20	900	0.275	Diethyl ether	C ₄ H ₁₀ O	25	985	0.311
Bromofom	CHBr ₃	20	918	0.654	Diethylene glycol	C ₄ H ₁₀ O ₃	25	1586	
n-butane	C ₄ H ₁₀	-5	1085		Diethylene glycol, monoethyl ether	C ₆ H ₁₄ O ₃	25	1458	
2-butanol	C ₄ H ₁₀ O	25	1240	3.239	Diethylenimide oxide	C ₄ H ₉ NO	25	1442	
sec-butylalcohol	C ₄ H ₁₀ O	25	1240	3.239	1, 2-bis (difluoramino) butane	C ₄ H ₈ (NF ₂) ₂	25	1000	
n-butyl bromide	C ₄ H ₉ Br	20	1019	0.49 (15°C)	1, 2-bis (difluoramino)-2-methylpropane	C ₄ H ₉ (NF ₂) ₂	25	900	
n-butyl chloride	C ₄ H ₉ Cl	25	1140	0.529	1, 2-bis (difluoramino) propane	C ₃ H ₆ (NF ₂) ₂	25	960	
tert butyl chloride	C ₄ H ₉ Cl	25	984	0.646	2, 2-bis (difluoramino) propane	C ₃ H ₆ (NF ₂) ₂	25	890	
Butyl oleate	C ₂₂ H ₄₂ O ₂	25	1404	0.529					
2,3 butylene glycol	C ₄ H ₁₀ O ₂	25	1484						
Carbinol	CH ₄ O	25	1076	0.695					
Carbitol	C ₆ H ₁₄ O ₃	25	1458						
Carbon dioxide	CO ₂	-37	839	0.137					
Carbon disulphide	CS ₂	20	1158	0.290					
Carbon tetrachloride	CCl ₄	20	938	0.608					
Cetane	C ₁₆ H ₃₄	20	1338	4.32					
Chlorobenezene	C ₆ H ₅ Cl	20	1289	0.722 (25°C)					

1-Chlorobutane	C ₄ H ₉ Cl	25	1140	0.529	2, 2-dihydroxy-dilethyrther	C ₄ H ₁₀ O ₃	25	1586	
Chloroform	CHCl ₃	20	931	0.383	Dihydroxyethane	C ₂ H ₆ O ₂	25	1658	
1-chloropropane	C ₃ H ₇ Cl	25	1058	0.378	Hexadecane	C ₁₆ H ₃₄	25	1338	4.32(20°C)
1, 3-dimethyl-benzene	C ₈ H ₁₀	20	1343	0.749 (15°C)	Hexalin	C ₁₆ H ₁₂	25	1454	70.69(17°C)
1, 2-dimethyl-benzene	C ₈ H ₁₀	25	1331.5	0.903 (20°C)	Hexane	C ₆ H ₁₄	25	1112	0.446
1, 4-dimethyl-benzene	C ₈ H ₁₀	20	1334	0.662	n-hexane	C ₆ H ₁₄	20	1083	0.489
2,2-dimethyl-butane	C ₆ H ₁₄	25	1079		2, 5-hexanedione	C ₆ H ₁₀ O ₂	25	1399	
Dimethyl ketone	C ₃ H ₆ O	25	1174	0.399	n-hexanol	C ₆ H ₁₄ O	25	1300	
Dimethyl pentane(47)	C ₇ H ₁₆	25	1063		Hexahydrobenzene	C ₆ H ₁₂	25	1248	1.31(17°C)
Dimethyl phthalate	C ₈ H ₁₀ O ₄	25	1463		Hexahydrophenol	C ₆ H ₁₂ O	25	1454	
Diiodo-methane	CH ₂ I ₂	25	980		Hexamethylene	C ₆ H ₁₂	25	1248	1.31
Dioxane	C ₄ H ₈ O ₂	25	1376		2-hydroxy-toluene	C ₇ H ₈ O	20	1541	4.29 (40°C)
Dodecane (23)	C ₁₂ H ₂₆	25	1279	1.80	3-hydroxy-toluene	C ₇ H ₈ O	20	1500	5.979 (40°C)
1, 2-ethanediol	C ₂ H ₆ O ₂	25	1658		Iodo-benzene	C ₆ H ₅ I	20	1114	0.954
Ethanenitrile	C ₂ H ₃ N	25	1290	0.441	Iodo-ethane	C ₂ H ₅ I	20	876	0.29
Ethanoic anhydride(22)	(CH ₃ CO) ₂ O	25	1180	0.769	Iodo-methane	CH ₃ I	25	978	0.211
Ethanol	C ₂ H ₆ O	25	1207	1.39	Isobutyl acetate	C ₆ H ₁₂ O	27	1180	
Ethanol amide	C ₂ H ₇ NO	25	1724		Isobutanol	C ₄ H ₁₀ O	25	1212	
Ethoxyethane	C ₄ H ₁₀ O	25	985	0.311	Iso-butane		25	1219.8	0.34
Ethyl acetate	C ₄ H ₈ O ₂	20	1164	0.499	Isopentane	C ₅ H ₁₂	25	980	0.34
Ethyl alcohol	C ₂ H ₆ O	25	1207	1.396	Isopropanol (46)	C ₃ H ₈ O	20	1170	2.718
Ethyl benzene	C ₈ H ₁₀	20	1338	0.797(17°C)	Isopropyl alcohol	C ₃ H ₈ O	20	1170	2.718
Ethyl Bromide	C ₂ H ₅ Br	20	900	0.275	Kerosene		25	1324	
Ethyl iodide	C ₂ H ₅ I	20	876	0.29	Ketohexamethylene	C ₆ H ₁₀ O	25	1423	
Ether	C ₄ H ₁₀ O	20	1006	0.336	Mercury	Hg	20	1451	0.114
Ethyl ether	C ₄ H ₁₀ O	25	985	0.311	Mesityloxiide	C ₆ H ₁₆ O	25	1310	
Ethylene bromide	C ₂ H ₄ Br ₂	25	995	0.79	Methanol	CH ₄ O	25	1076	0.695
Ethylene chloride	C ₂ H ₄ Cl ₂	25	1193	0.61	Methyl acetate	C ₃ H ₆ O ₂	20	1181	0.411
Ethylene glycol	C ₂ H ₆ O ₂	20	1666	21.112	o-methylaniline	C ₇ H ₉ N	25	1618	4.394 (20°C)
50% glycol/50% H ₂ O		25	1578		4-methylaniline	C ₇ H ₉ N	25	1480	1.863 (50°C)
d-fenochone	C ₁₀ H ₁₆ O	25	1320	0.22	Methyl alcohol	CH ₄ O	25	1076	0.695
d-2- fenochone	C ₁₀ H ₁₆ O	25	1320	0.22	Methyl benzene	C ₇ H ₈	20	1328	0.644
Fluoro-benzene (46)	C ₆ H ₅ F	25	1189	0.584	2-methyl-butane	C ₅ H ₁₂	25	980	0.34
Formaldehyde, methylester	C ₂ H ₄ O ₂	25	1127		Methyl carbinol	C ₂ H ₆ O	25	1207	1.396
Formamide	CH ₃ NO	25	1622	2.91	Methyl-chloroform	C ₂ H ₃ Cl ₃	25	985	0.902 (20°C)
Formic acid, amide	CH ₃ NO	25	1622	2.91	Methyl-cyanide	C ₂ H ₃ N	25	1290	0.441
Freon R12		25	774.2		3-methyl cyclohexanol	C ₇ H ₁₄ O	25	1400	
Furfural	C ₅ H ₄ O ₂	25	1444		Methylene chloride	CH ₂ Cl ₂	25	1070	0.31
Furfuryl alcohol	C ₅ H ₆ O ₂	25	1450		Methylene iodide	CH ₂ I ₂	25	980	
Fural	C ₅ H ₄ O ₂	25	1444		Methyl formate	C ₂ H ₄ O ₂	25	1127	
2-furaldehyde	C ₅ H ₄ O ₂	25	1444		Methyl iodide	CH ₃ I	25	978	0.211
2-furancarboxalde-hyde	C ₅ H ₄ O ₂	25	1444		α-methyl naphthalene	C ₁₁ H ₁₀	25	1510	
2-furyl-methanol	C ₅ H ₆ O ₂	25	1450		2-methylphenol	C ₇ H ₈ O	20	1541	4.29 (40°C)
Gallium	Ga	30	2870		3-methylphenol	C ₇ H ₈ O	20	1500	5.979 (40°C)
Glycerin	C ₃ H ₈ O ₃	20	1923	1188.5	Milk, homogenized		25	1548	
Glycerol	C ₃ H ₈ O ₃	25	1904	757.1	Morpholine	C ₄ H ₉ NO	25	1442	
Glycol	C ₂ H ₆ O ₂	25	1658		Naphtha		25	1225	

Heptane	C ₇ H ₁₆	25	1131	0.598(20°C)	Nitrobenzene	C ₆ H ₅ NO ₂	20	1473	1.665
n-heptane	C ₇ H ₁₆	25	1180		Nitromethane	CH ₃ NO ₂	25	1300	0.549
Hexachloro-cyclopentadiene	C ₅ Cl ₆	25	1150		Nonane	C ₉ H ₂₀	25	1207	0.99(20°C)
Octane	C ₈ H ₁₈	25	1172	0.73	1-nonene	C ₉ H ₁₈	25	1207	
n-octane	C ₈ H ₁₈	20	1192	0.737(25°C)	Refrigerant 21	CHCl ₂ F	0	891	
1-octene	C ₈ H ₁₆	25	1175.5		Refrigerant 22	CHClF ₂	50	893.9	
Oil of camphor Sassafrassy		25	1390		Refrigerant 113	CCl ₂ F-CClF ₂	0	783.7	
Oil, car(SAE 20a.30)		25	870	190	Refrigerant 114	CClF ₂ -CClF ₂	-10	665.3	
Oil, castor	C ₁₁ H ₁₀ O ₁₀	25	1477	0.670	Refrigerant 115	C ₂ ClF ₅	-50	656.4	
Oil, diesel		25	1250		Refrigerant C318	C ₄ F ₈	-10	574	
Oil, fuel AA gravity		25	1485		Silicone (30cp)		25	990	30
Oil (Lubricating X200)		25	1530		Solvesso #3		25	1370	
Oil (olive)		25	1431	100	Spirit of wine	C ₂ H ₆ O	25	1207	1.396
Oil (peanut)		25	1458		Sulfuric Acid	H ₂ SO ₄	25	1257.6	11.16
Oil (sperm)		25	1440		1, 1, 2, 2-tetrabromo-ethane	C ₂ H ₂ Br ₄	25	1027	
Oil, 6		22	1509		1, 1, 2, 2-tetrachloro-ethane	C ₂ H ₂ Cl ₄	25	1147	1.156 (15°C)
2, 2-oxydiethanol	C ₄ H ₁₀ O ₃	25	1586		Tetrachloroethane	C ₂ H ₂ Cl ₄	20	1170	1.19
Pentachloroethane	C ₂ HCl ₅	25	1082		Tetrachloroethene	C ₂ Cl ₄	25	1036	
Pentalin	C ₂ HCl ₅	25	1082		Tetrachloro-Methane	CCl ₄	25	926	0.607
Pentane	C ₅ H ₁₂	25	1020	0.363	Tetradecane	C ₁₄ H ₃₀	20	1331	2.86
n-pentane	C ₅ H ₁₂	20	1032	0.366	Tetraethylene glycol	C ₈ H ₁₈ O ₅	25	1586	
Perchlorocyclo-pentadiene	C ₅ Cl ₆	25	1150		Tetrahydro-1, 4-isoxazine	C ₄ H ₉ NO	25	1442	
Perchloroethylene	C ₂ Cl ₄	25	1036		Toluene	C ₇ H ₈	20	1328	0.644
Perchloro-1-hepten	C ₇ F ₁₄	25	583		o-toluidine	C ₇ H ₉ N	25	1618	4.394 (20°C)
Perfluoro-n-hexane	C ₆ F ₁₄	25	508		p-toluidine	C ₇ H ₉ N	25	1480	1.863 (50°C)
Phene	C ₆ H ₆	25	1306	0.711	Toluol	C ₇ H ₈	25	1308	0.58
β-phenyl acrolein	C ₉ H ₈ O	25	1554		Tribromomethane	CHBr ₃	25	918	0.654
Phenyl amine	C ₆ H ₅ NO ₂	25	1639	3.63	1, 1, 1-trichloro-ethane	C ₂ H ₃ Cl ₃	25	985	0.902 (20°C)
Phenyl bromide	C ₆ H ₅ Br	20	1170	0.693	Trichloro-ethene	C ₂ HCl ₃	25	1028	
Phenyl chloride	C ₆ H ₅ Cl	25	1273	0.722	Trichloro-fluoromethane (Freon 11)	CCl ₃ F	0	828.3	
Phenyl iodide	C ₆ H ₅ I	20	1114	0.954(15°C)	Trichloro-methane	CHCl ₃	25	979	0.55
Phenyl methane	C ₇ H ₈	20	1328	0.644	1, 1, 2-trichloro- 1, 2, 2-trifluoro-etham	CCl ₂ F-CClF ₂	0	783.7	
3-Phenyl propenal	C ₉ H ₈ O	25	1554		Triethylamine	C ₆ H ₁₅ N	25	1123	
Phthalardione	C ₈ H ₄ O ₃	152	1125		Triethylene glycol	C ₆ H ₁₄ O ₄	25	1608	
Pimelic ketone	C ₆ H ₁₀ O	25	1423		1, 1, 1-trifluoro- 2-chloro-2-bromo-ethane	C ₂ HClBrF ₃	25	693	
Plexiglas, lucite, acrylic		25	2651		1, 2, 2-trifluorotrichlo- ethane (Freon 113)	CCl ₂ F-CClF ₂	0	783.7	
Refrigerant 11	CCl ₃ F	0	828.3		d-1,3,3-trimethylnorcamphor	C ₁₀ H ₁₆ O	25	1320	0.22
Propane	C ₃ H ₈	-45	1003		Trinitrotoluene	C ₇ H ₅ (NO ₂) ₃	81	1610	
1, 2, 3-propanetriol	C ₃ H ₈ O ₃	25	1904	0.757x10 ⁻³	Turpentine		25	1255	1.4
1-propanol	C ₃ H ₈ O	20	1222		Unisis 800		25	1346	
2-propanol	C ₃ H ₈ O	20	1170	2.718	Water, distilled	H ₂ O	20	1482	1.00
2-propanone	C ₃ H ₆ O	25	1174	0.399	Water, heavy	D ₂ O	20	1388	1.129
Propene	C ₃ H ₆	-13	963		Water, sea		20	1520	1.00
n-propyl acetate	C ₅ H ₁₀ O ₂	2	1280		Wood alcohol	CH ₄ O	25	1076	0.695
n-propyl alcohol	C ₃ H ₈ O	20	1225	2.549	m-xylene	C ₈ H ₁₀	20	1343	0.749 (15°C)
Propylchloride	C ₃ H ₇ Cl	25	1058	0.378					

Propylene	C ₃ H ₆	-13	963		o-xylene	C ₈ H ₁₀	25	1331.5	0.903 (20°C)
Pyridine	C ₆ H ₅ N	25	1415	0.992(20°C)	p-xylene	C ₈ H ₁₀	20	1334	0.662
Refrigerant 11	CCl ₃ F	0	828.3		Xylene hexafluoride	C ₈ H ₄ F ₆	25	879	0.613
Refrigerant 12	CCl ₂ F ₂	-40	774.1						

9. 4 Material Sound Velocity(at 25 °C)

Unit : Velocity (m/s)

Pipe material	Sound velocity	Pipe material	Sound velocity	Pipe material	Sound velocity
Steel 1% Carbon,hardened	3150	CuNi (90%Cu 10%Ni)	2060	Zinc, rolled	2440
Carbon Steel	3206	Brass (Naval)	2270(2050)	Glass, Pyrex	3276(3280)
Mild Steel	3235	Gold(hard-brawn)	1200	Glass, heavy silicate flint	2380
Steel 1% Carbon	3220	Inconel	3020	Glass,light borate crown	2840
Stainless Steel 302	3120	Iron (electrolytic)	3240	Nylon	2400
Stainless Steel 303	3120	Cast Iron	2460(3230)	Nylon,6-6	1070
Stainless Steel 304	3206	Lead	2170	Polyelathylene	1950
Stainless Steel 316	3175	Teflon	1225(1240)	Polyethylene(HD)	2310
Stainless Steel 347	3100	Iron(Armco)	3230	Polyethylene(LD)	1940
Stainless Steel 410	2990	Ductile Iron	3000	PVC, CPVC	2540(2400)
Stainless Steel 430	3360	Monel	2720	Acrylic	2730
Aluminum	3048(3080)	Nickel	2960	Asbestos Cement	2200
Aluminum (rolled)	3040	Tin, rolled	1670	Cement	4190
Copper	2260	Titanium	3150(3125)	Mortar	2500
Copper (annealed)	2325	Tungsten,annealed	2890	Rubber	1600(1900)
Copper (rolled)	2270	Tungsten, drawn	2640	FRP	2505
CuNi (70%Cu 30%Ni)	2540	Tungsten, carbide	3980	Teflon 1	1450
Tar Epoxy	2000	Plastic	2280	ABS	2286

9.5 Sound Velocity in Water (St.Pres 1.01325bar)

Unit : Temp. (°C), Velocity (m/s)

Temp. (°C)	Sound velocity (m/s)	Temp. (°C)	Sound velocity (m/s)	Temp. (°C)	Sound velocity (m/s)	Temp. (°C)	Sound velocity (m/s)
0	1402.3	25	1496.6	50	1542.5	75	1555.1
1	1407.3	26	1499.2	51	1543.5	76	1555.0
2	1412.2	27	1501.8	52	1544.6	77	1554.9
3	1416.9	28	1504.3	53	1545.5	78	1554.8
4	1421.6	29	1506.7	54	1546.4	79	1554.6
5	1426.1	30	1509.0	55	1547.3	80	1554.4
6	1430.5	31	1511.3	56	1548.1	81	1554.2
7	1434.8	32	1513.5	57	1548.9	82	1553.9
8	1439.1	33	1515.7	58	1549.6	83	1553.6
9	1443.2	34	1517.7	59	1550.3	84	1553.2
10	1447.2	35	1519.7	60	1550.9	85	1552.8
11	1451.1	36	1521.7	61	1551.5	86	1552.4
12	1454.9	37	1523.5	62	1552.0	87	1552.0
13	1458.7	38	1525.3	63	1552.5	88	1551.5
14	1462.3	39	1527.1	64	1553.0	89	1551.0
15	1465.8	40	1528.8	65	1553.4	90	1550.4
16	1469.3	41	1530.4	66	1553.7	91	1549.8
17	1472.7	42	1532.0	67	1554.0	92	1549.2
18	1476.0	43	1533.5	68	1554.3	93	1548.5
19	1479.1	44	1534.9	69	1554.5	94	1547.5
20	1482.3	45	1536.3	70	1554.7	95	1547.1
21	1485.3	46	1537.7	71	1554.9	96	1546.3
22	1488.2	47	1538.9	72	1555.0	97	1545.6
23	1491.1	48	1540.2	73	1555.0	98	1544.7
24	1493.9	49	1541.3	74	1555.1	99	1543.9

NOR. OD	S/N	OUTDIAMETER		WALL THICKNESS		INNER DIAMETER		NOR. OD	S/N	OUTDIAMETER		WALL THICKNESS		INNER DIAMETER	
		INCH	mm	INCH	mm	INCH	mm			INCH	mm	INCH	mm	INCH	mm
10	80	10.750	273.050	0.594	15.088	9.562	242.875	18	10	18.000	457.200	0.250	6.350	17.500	444.500
	100			0.719	18.263	9.312	236.225		20			0.312	7.925	17.376	441.350
	120			0.844	21.438	9.062	230.175		Std			0.375	9.525	17.250	438.150
	140			1.000	25.400	8.750	222.250		30			0.438	11.125	17.124	434.950
	160			1.125	28.575	8.500	215.900		XS			0.500	12.700	17.000	431.800
12	5S	12.750	323.850	0.165	4.191	12.420	315.468	20	40	20.000	508.000	0.562	14.275	16.876	428.650
	10S			0.180	4.572	12.390	314.706		60			0.625	15.875	16.750	425.450
	20			0.250	6.350	12.250	311.150		80			0.688	17.475	16.624	422.250
	30			0.330	8.382	12.090	307.086		100			0.750	19.050	16.500	419.100
	Std/40S			0.375	9.525	12.000	304.800		120			0.875	22.225	16.250	412.750
	40			0.406	10.312	11.938	303.225		140			0.938	23.825	16.124	409.550
	XS/80S			0.500	12.700	11.750	298.450		160			1.156	29.362	15.688	398.475
	60			0.562	14.275	11.626	295.300		10			1.375	34.925	15.250	387.350
	80			0.688	17.475	11.374	288.900		20/Std			1.562	39.675	14.876	377.850
	100			0.844	21.438	11.062	280.975		30/XS			1.781	45.237	14.438	366.725
	120			1.000	25.400	10.750	273.050		40			0.250	6.350	19.500	495.300
	140			1.125	28.575	10.500	266.700		60			0.312	7.925	19.376	492.150
	160			1.312	33.325	10.126	257.200		80			0.375	9.525	19.250	488.950
14	10	14.000	355.600	0.250	6.350	13.500	342.900	24	10	24.000	609.600	0.438	11.125	19.124	485.750
	20			0.312	7.925	13.376	339.750		20/Std			0.500	12.700	19.000	482.600
	30/Std			0.375	9.525	13.250	336.550		30/XS			0.562	14.275	18.876	479.450
	40			0.438	11.125	13.124	333.350		40			0.594	15.088	18.812	477.825
	XS			0.500	12.700	13.000	330.200		60			0.625	15.875	18.750	476.250
	60			0.562	14.275	12.876	327.050		80			0.688	17.475	18.624	473.050
	80			0.594	15.088	12.812	325.425		100			0.750	19.050	18.500	469.900
	100			0.625	15.875	12.750	323.850		120			0.812	20.625	18.376	466.750
	120			0.688	17.475	12.624	320.650		140			0.875	22.225	18.250	463.550
	140			0.750	19.050	12.500	317.500		160			1.031	26.187	17.938	455.625
	160			0.875	22.225	12.250	311.150		10			1.281	32.537	17.438	442.925
	10			0.938	23.825	12.124	307.950		20/Std			1.500	38.100	17.000	431.800
	20			1.094	27.788	11.812	300.025		30/XS			1.750	44.450	16.500	419.100
	30/Std			1.250	31.750	11.500	292.100		40			1.969	50.013	16.062	407.975
	40/XS			1.406	35.712	11.188	284.175		60			0.250	6.350	23.500	596.900
16	10	16.000	406.400	0.250	6.350	15.500	393.700	30	10	30.000	762.000	0.312	7.925	23.376	593.750
	20			0.312	7.925	15.376	390.550		20/Std			0.375	9.525	23.250	590.550
	30/Std			0.375	9.525	15.250	387.350		30			0.438	11.125	23.124	587.350
	40/XS			0.438	11.125	15.124	384.150		40			0.500	12.700	23.000	584.200
	60			0.500	12.700	15.000	381.000		60			0.562	14.275	22.876	581.050
	80			0.562	14.275	14.876	377.850		80			0.625	15.875	22.750	577.850
	100			0.625	15.875	14.750	374.650		100			0.688	17.475	22.624	574.650
	120			0.656	16.662	14.688	373.075		120			0.750	19.050	22.500	571.500
	140			0.688	17.475	14.624	371.450		140			0.969	24.613	22.062	560.375
	160			0.750	19.050	14.500	368.300		160			1.219	30.963	21.562	547.675
	10			0.844	21.438	14.312	363.525		10			1.531	38.887	20.938	531.825
	20			0.875	22.225	14.250	361.950		20			1.812	46.025	20.376	517.550
	30			1.031	26.187	13.938	354.025		30			2.062	52.375	19.876	504.850
	40			1.219	30.963	13.562	344.475		40			2.344	59.538	19.312	490.525
	50			1.438	36.525	13.124	333.350		10			0.312	7.925	29.376	746.150
	60			1.594	40.488	12.812	325.425		20			0.500	12.700	29.000	736.600
									30			0.625	15.875	28.750	730.250